

HONDA

Power

Equipment

Owner's Manual

Snowthrower

HS520A • HS520AS



See page 39 for instructions on setting up your Snowthrower.

**WARNING:**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Keep this owner's manual handy, so you can refer to it any time. This owner's manual is considered a permanent part of the snowthrower and should remain with the snowthrower if resold.

The information and specifications included in this publication were in effect at the time of approval for printing. American Honda Motor Co., Inc. reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation whatever. No part of this publication may be reproduced without written permission.

INTRODUCTION

Congratulations on your selection of a Honda snowthrower. We are certain you will be pleased with your purchase of one of the finest snowthrowers on the market.

We want to help you get the best results from your new snowthrower and to operate it safely. This manual contains the information on how to do that; please read it carefully.

As you read this manual, you will find information preceded by a **NOTICE** symbol. That information is intended to help you avoid damage to your snowthrower, other property, or the environment.

We suggest you read the *Distributor's Limited Warranty* (page 50) and the *Emission Control System Warranty* (page 52) to fully understand its coverage and your responsibilities of ownership.

When your snowthrower needs scheduled maintenance, keep in mind that your servicing Honda dealer is specially trained in servicing Honda snowthrowers. Your Honda servicing dealer is dedicated to your satisfaction and will be pleased to answer your questions and concerns.

Best Wishes,

American Honda Motor Co., Inc.
Power Equipment Division

INTRODUCTION

A FEW WORDS ABOUT SAFETY

Your safety and the safety of others is very important, and using this snowthrower safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all the hazards associated with operating or maintaining a snowthrower. You must use your own good judgment.

You will find important safety information in a variety of forms including:

- **Safety Labels** — on the snowthrower.
- **Safety Messages** — preceded by a safety alert symbol  and one of three signal words: DANGER, WARNING, or CAUTION.

These signal words mean:

 **DANGER**

You **WILL** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

 **WARNING**

You **CAN** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

 **CAUTION**

You **CAN** be **HURT** if you don't follow instructions.

- **Safety Headings** — such as *IMPORTANT SAFETY INFORMATION*.
- **Safety Section** — such as *SNOWTHROWER SAFETY*.
- **Instructions** — how to use this snowthrower correctly and safely.

This entire book is filled with important safety information — please read it carefully.

CONTENTS

SNOWTHROWER SAFETY	4
IMPORTANT SAFETY INFORMATION	4
SAFETY LABEL LOCATIONS	7
CONTROLS & FEATURES	8
COMPONENT & CONTROL LOCATIONS	8
CONTROLS	9
BEFORE OPERATION	11
ARE YOU READY TO GET STARTED?	11
IS YOUR SNOWTHROWER READY TO GO?	11
CHECK YOUR WORK AREA	12
OPERATION	13
SNOWTHROWING PRECAUTIONS	13
STARTING THE ENGINE	13
STOPPING THE ENGINE	16
CLEARING SNOW	17
SNOW-CLEARING TIPS	18
REMOVING OBSTRUCTIONS	18
SERVICING YOUR SNOWTHROWER	19
THE IMPORTANCE OF PROPER MAINTENANCE	19
MAINTENANCE SAFETY	20
MAINTENANCE SCHEDULE	21
REFUELING	22
FUEL RECOMMENDATIONS	23
ENGINE OIL	23
SPARK PLUG SERVICE	25
AUGER	27
SCRAPER BLADE	29
STORAGE	31
STORAGE PREPARATION	31
STORAGE PRECAUTIONS	34
REMOVAL FROM STORAGE	34
TRANSPORTING	35
BEFORE LOADING	35
LOADING AND UNLOADING	35
TAKING CARE OF UNEXPECTED PROBLEMS	36
SET-UP	39
TECHNICAL & CONSUMER INFORMATION	42
TECHNICAL INFORMATION	42
EMISSION CONTROL SYSTEM	45
SPECIFICATIONS	48
CONSUMER INFORMATION	49
INDEX	56
QUICK REFERENCE INFORMATION	inside back cover

SNOWTHROWER SAFETY

IMPORTANT SAFETY INFORMATION

Honda snowthrowers are designed to clear snow from driveways and walkways. Other uses can result in injury to the operator or damage to the snowthrower and other property.

Most accidents with snowthrowers can be prevented if you follow all instructions in this manual and on the snowthrower. The most common hazards, according to accident statistics, are discussed below, along with the best way to protect yourself and others.

Avoid Rotating Auger

The snowthrower auger can cause serious cuts and even amputate fingers, hands, toes, or feet. Keep away from the auger whenever the engine is running. If you need to work around the snowthrower to clear snow for any reason, always shut off the engine. If the snow discharge chute becomes clogged, stop the engine and disconnect the spark plug cap. Use a wooden stick to remove the obstruction. Never put your hand into the snow discharge chute while the engine is running; serious personal injury could result.

Clear Operation Area

The snowthrower can throw rocks and other objects with enough force to cause serious injury. Before operating the snowthrower, carefully inspect the area and remove all obvious hazards. Never use the snowthrower to clear snow from a gravel road or driveway, as rocks may be picked up and ejected. They may cause injury to bystanders.

Keep Shields in Place

Guards and shields are designed to protect you from being hit by thrown objects and to keep you from touching hot engine parts and moving components. For your safety and the safety of others, keep all shields in place when the engine is running.

Adjust the snow discharge chute to avoid hitting the operator, bystanders, windows, and other objects with ejected snow. Stay clear of the snow discharge chute while the engine is running.

Children and pets must be kept away from the area of operation to avoid injury from flying debris and contact with the snowthrower.

Refuel with Care

Gasoline is extremely flammable, and gasoline vapor can explode. Allow the engine to cool if the snowthrower has been in operation. Refuel only outdoors in a well-ventilated area with the engine OFF. Never fill the fuel tank beyond the maximum fill mark. Never smoke near gasoline, and keep other flames and sparks away. Always store gasoline in an approved container.

Turn Engine Off When Not Operating the Snowthrower

If you need to leave the snowthrower for any reason, even just to inspect the area ahead, always turn the engine off.

Operation on Slopes

To avoid overturning, be careful when changing the direction of the snowthrower while operating it on a slope. Do not use the snowthrower to remove snow from roofs. The snowthrower may overturn on steep slopes if left unattended, causing injury to the operator or bystanders.

Operating Conditions

Do not use the snowthrower when visibility is poor. Under conditions of poor visibility, there is a greater risk of striking an obstacle or causing injury. Adjust the snow discharge chute to avoid hitting passing bystanders or vehicles. Stay clear of the snow discharge chute while the engine is running.

SNOWTHROWER SAFETY

Operating Near Roads

Always watch for vehicle traffic when operating the snowthrower near roads and driveways. Never operate the snowthrower on public roads.

Operator Responsibility

Know how to stop the snowthrower quickly in case of emergency. Understand the use of all snowthrower controls.


Never permit anyone to operate the snowthrower without proper instruction. Do not let children operate the snowthrower. If people or pets suddenly appear in front of the snowthrower while it is in operation, immediately release the auger and drive clutch lever to stop the snowthrower and avoid possible injury from the rotating auger.

While operating the snowthrower, hold the handle firmly, and walk, don't run. Wear suitable winter boots that resist slipping.

SNOWTHROWER SAFETY

SAFETY LABEL LOCATIONS


These labels warn you of potential hazards that can cause serious injury. Read them carefully. If a label comes off or becomes hard to read, contact your Honda snowthrower dealer for a replacement.




CONTROLS & FEATURES

COMPONENT & CONTROL LOCATIONS

Use the two illustrations on this page to locate and identify the most frequently used controls.




HS520AS



CONTROLS


Fuel Valve

The fuel valve opens and closes the fuel line leading from the fuel tank to the carburetor. Make sure that the fuel valve is positioned exactly at either the ON or OFF position. When the snowthrower is not in use, always leave the fuel valve in the OFF position to reduce the possibility of fuel leakage.




Engine Switch

The engine switch controls the ignition system. The HS520A has an OFF-ON-OFF switch, while the HS520AS has a key that controls an OFF-ON switch. OFF — Stops the engine. ON — Running position, and for starting with the recoil or electric starter (HS520AS).




Starter Button (HS520AS)

The starter button is used to operate the electric starter when a household extension cord is plugged into the starter box.



Starter Grip

Pull this grip to start the engine.




CONTROLS & FEATURES

Choke Knob


The choke knob is used to open or close the choke. CLOSED is used when the engine is cold.

The OPEN position provides the correct fuel mixture for operation after the engine has warmed up, and for starting a warm engine.



Chute Guide Handle


Use this control to guide the snow discharge angle and direction.



Auger Clutch Lever

When this lever is engaged, the snowthrower auger paddles begin to spin and the snowthrower will move forward.

Do not engage the auger clutch lever on cleared ground or the snowthrower will move forward suddenly.



BEFORE OPERATION

ARE YOU READY TO GET STARTED?

Your safety is your responsibility. A little time spent in preparation will significantly reduce your risk of injury.

Knowledge

Read and understand this manual. Know what the controls do and how to operate them.

Familiarize yourself with the snowthrower and its operation before you begin using it. Know how to shut off the snowthrower quickly in case of an emergency.

IS YOUR SNOWTHROWER READY TO GO?

For your safety, and to maximize the service life of your equipment, it is very important to take a few moments before you operate the snowthrower to check its condition. Be sure to take care of any problem you find, or have your servicing dealer correct it, before you operate the snowthrower.

WARNING

Improperly maintaining this snowthrower, or failing to correct a problem before operation, could cause a malfunction in which you could be seriously injured.

Always perform a preoperation inspection before each operation, and correct any problem.

Before beginning your preoperation checks, be sure the snowthrower is on a level surface and the engine switch is in the OFF position.

BEFORE OPERATION

Check the General Condition of the Snowthrower

- Look around and underneath the snowthrower for signs of oil or gasoline leaks.
- Check the auger housing and the discharge chute for accumulation of packed snow or ice. Clean the auger housing and discharge chute before starting the snowthrower.
- Look for signs of damage.
- Check each control for proper operation.
- Check auger paddles for wear. Replace if necessary (page 28).
- Check the scraper blade for wear. Replace if necessary (page 30).
- Check that all nuts, bolts, and screws are tightened.

Check the Engine

- Check the oil level (page 23).
- Check the fuel level (page 22). Starting with a full tank will help to eliminate or reduce operating interruptions for refueling.

CHECK YOUR WORK AREA

For your safety and the safety of others, always inspect the area before operating the snowthrower.

Objects

Anything which can be picked up by the auger and thrown is a potential hazard to you and others. Look for hazards and remove them from the work area.

People and Pets

People and animals near the work area can move into your snowthrower's path or into a position where they could be struck by thrown objects. Clear the area of people, especially children and pets. Their safety is your responsibility.

Work Area

Check the condition of the snow. Adjust your snowthrower ground speed and snowblowing swath accordingly.

Check the scraper blade for proper adjustment. Check the scraper blade for the correct auger ground clearance (page 29).

OPERATION

SNOWTHROWING PRECAUTIONS

Before operating the snowthrower for the first time, please review both the *SNOWTHROWER SAFETY* chapter (page 4) and the *BEFORE OPERATION* chapter (page 11).

Even if you have operated other snowthrowers, take time to become familiar with how this snowthrower works, and practice in a safe area until you build up your skills.

Never tamper with or alter any of the controls or safety devices on the snowthrower.

For your safety, avoid starting or operating the engine in an enclosed area such as a garage. Your snowthrower's exhaust contains poisonous carbon monoxide gas which can collect rapidly in an enclosed area and cause illness or death.


WARNING

Carbon monoxide gas is toxic. Breathing it can cause unconsciousness and even kill you.

Avoid any enclosed areas or activities that expose you to carbon monoxide.


STARTING THE ENGINE

1. Turn the fuel valve to the ON position.




OPERATION

2. If the engine is cold, pull the choke knob out to the CLOSED position.



3. Start the engine.
Electric Start (AS model only):


- a. Connect an extension cord (commercially available) to the starter box first, then to a 120 volt ac outlet.




Use an outdoor power cord with a power rating of no less than 15 amps. Do not connect and disconnect the power cord with wet hands. Do not use in the rain.

Be sure to hold the plug when disconnecting the power cord from the electrical outlet or starter box. Do not disconnect by pulling on the power cord.

- b. Turn the engine switch to the ON position.



- c. Push the starter button until the engine starts. After the engine starts, disconnect the power cord from the electrical outlet, and then from the starter box.





NOTICE

To prevent damage to the starter, do not operate the starter for more than 15 seconds. If the engine fails to start, release the button and allow the starter to cool for 10 minutes before operating it again.

Manual (Pull) Starting


- a. Turn the engine switch to the ON position.



- b. Pull the starter grip slowly until you feel resistance, then pull briskly.
- c. Return the starter grip gently.

NOTICE

To prevent damage to the recoil starter, do not allow the starter grip to snap back against the starter bracket. Return it gently to prevent damage. Do not pull the starter grip while the engine is running. The starter could be damaged.



OPERATION

- Let the engine warm up for several minutes. If the choke knob has been pulled to the CLOSED position to start the engine, gradually push it to the OPEN position as the engine warms up.



STOPPING THE ENGINE

To stop the engine in an emergency, turn the engine switch to the OFF position. Under normal conditions, use the following procedure.


- Release the auger clutch lever.
The auger will stop operation.



- Turn the engine switch to the OFF position.




- Turn the fuel valve to the OFF position.



CLEARING SNOW

1. Press down on the handlebar to raise the front of the snowthrower slightly. Roll the snowthrower over to the snow area.
2. Use the chute guide handle (page 10) to adjust the direction for the discharged snow to travel.
3. Engage the auger clutch lever. The auger will begin to spin.
4. Tilt the snowthrower forward slightly with the handlebar to engage the auger into the snow. The auger will then pull the snowthrower forward and discharge the snow.
5. To stop, lower the handlebar slightly, then release the auger clutch lever.



OPERATION

SNOW-CLEARING TIPS

For best efficiency, clear snow before it melts, refreezes and hardens.

Operating tips for clearing hard or deep snow:

- Clear snow with a back and forth motion. Release the auger clutch lever, then press down on the handlebar to raise the auger housing when pulling the snowblower backwards.
- Clear a narrower swath. Make several passes with the auger overlapping the cleared areas.

REMOVING OBSTRUCTIONS

If the discharge chute or snowthrowing mechanism becomes restricted:

1. Stop the engine.
2. Make sure that all rotating parts have come to a complete stop.
3. Remove the spark plug cap from the spark plug (page 25).
4. Use a wooden stick to clear the obstruction.

SERVICING YOUR SNOWTHROWER

THE IMPORTANCE OF PROPER MAINTENANCE

Proper maintenance is essential for safe, economical, and trouble-free operation. It will also help reduce air pollution.

To help you properly care for your snowthrower, the following pages include a maintenance schedule, routine inspection procedures, and simple maintenance procedures using basic hand tools. Other service tasks that are more difficult, or require special tools, are best handled by professionals and are normally performed by a Honda technician or other qualified mechanic.

The maintenance schedule applies to normal operating conditions. If you operate your snowthrower under unusual conditions, consult your servicing dealer for recommendations applicable to your individual needs and use. Remember that your servicing dealer knows your snowthrower best and is fully equipped to maintain and repair it.

WARNING

Improper maintenance, or failure to correct a problem before operation, can cause a malfunction in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

To ensure the best quality and reliability, use only new, genuine Honda parts or their equivalents for repair and replacement.

Maintenance, replacement, or repair of the emission control devices and systems may be performed by any engine repair establishment or individual, using parts that are “certified” to EPA standards.

SERVICING YOUR SNOWTHROWER

MAINTENANCE SAFETY

Some of the most important safety precautions follow. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

WARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in the owner's manual.

Safety Precautions

- Make sure the engine is off before you begin any maintenance or repairs. This will eliminate several potential hazards:
 - **Carbon monoxide poisoning from engine exhaust.**
Be sure there is adequate ventilation whenever you operate the engine.
 - **Burns from hot parts.**
Let the engine and exhaust system cool before touching.
 - **Injury from moving parts.**
Do not run the engine unless instructed to do so.
- Read the instructions before you begin, and make sure you have the tools and skills required.
- To reduce the possibility of fire or explosion, be careful when working around gasoline. Use only a nonflammable solvent, not gasoline, to clean parts. Keep cigarettes, sparks, and flames away from all fuel-related parts.

SERVICING YOUR SNOWTHROWER

MAINTENANCE SCHEDULE

REGULAR SERVICE PERIOD ITEM	Perform at every indicated interval	Before each use	First 25 hours	Every year		Every 150 hours	See page
				Before operation	Before storage		
Engine oil	Check	O					23
	Change		O	O (1)			24
Spark plug	Check-Adjust			O (1)	O		25
	Replace					O	
Auger clutch lever freeplay	Check-Adjust			O			27
Auger paddles	Check			O			28
Scraper blade	Check-Adjust	O		O (1)			29
Fuel tank and carburetor	Drain				O		32
Moving parts	Apply oil				O		33
Engine speed	Check-Adjust					O(2)	Shop manual
Fuel filter	Check					O(2)	Shop manual
Fuel line	Replace	Every 2 years (2)					Shop manual
Valve clearance	Check-Adjust					O(2)	Shop manual
Combustion chamber	Clean	After every 250 hours (2)					Shop manual

- (1) Service every 10 hours or daily when used under extremely harsh conditions, or if used commercially.
- (2) These items should only be serviced by an authorized Honda servicing snowthrower dealer unless you are mechanically proficient and have the proper tools.


Failure to follow this maintenance schedule could result in non-warrantable failures.

SERVICING YOUR SNOWTHROWER

REFUELING

FUEL TANK CAPACITY: 0.3 US gallon (1.3 liters)

Stop the engine, remove the cap, and check the fuel level. Refill the tank if the fuel level is low. Do not fill above the base of the filler neck.



⚠ WARNING

Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

Refuel in a well-ventilated area before starting the engine. If the engine has been running, allow it to cool. Refuel carefully to avoid spilling fuel. Do not fill the fuel tank above the base of the filler neck. After refueling, tighten the fuel tank cap securely.

Never refuel the engine inside a building where gasoline fumes may reach flames or sparks. Keep gasoline away from appliance pilot lights, barbecues, electric appliances, power tools, etc.

Spilled fuel is not only a fire hazard, it causes environmental damage. Wipe up spills immediately.

SERVICING YOUR SNOWTHROWER

FUEL RECOMMENDATIONS

Use unleaded gasoline with a pump octane rating of 86 or higher. The engine is certified to operate on unleaded gasoline. Unleaded gasoline produces fewer engine and spark plug deposits and extends exhaust system life. Never use stale or contaminated gasoline or an oil/gasoline mixture. Avoid getting dirt or water in the fuel tank. Occasionally you may hear a light “spark knock” or “pinging” (metallic rapping noise) while operating under heavy loads. This is no cause for concern. If spark knock or pinging occurs at a steady engine speed, under normal load, change brands of gasoline. If spark knock or pinging persists, see an authorized Honda servicing dealer.

NOTICE



Running the engine with persistent spark knock or pinging can cause engine damage. Running the engine with persistent spark knock or pinging is misuse, and the Distributor's Limited Warranty does not cover parts damaged by misuse.

ENGINE OIL

Oil Level Check

Check the engine oil level with the snowthrower stopped and in a level position.

1. Remove the oil filler cap/dipstick and wipe it clean.
2. Insert and remove the dipstick without screwing it into the filler neck.
3. If the level is low, fill to the edge of the oil filler hole with the recommended oil (page 25).
4. Reinstall the oil filler cap/dipstick.



NOTICE


Running the engine with a low oil level can cause engine damage.

SERVICING YOUR SNOWTHROWER

Engine Oil Change

Drain the oil while the engine is still warm to assure rapid and complete draining.

1. Place the snowthrower on a level surface.
2. Place a suitable container below the drain bolt to catch the used oil, then remove the oil filler cap/dipstick and the drain plug.
3. Allow the used oil to drain completely, then reinstall the drain plug, and tighten it securely.



NOTICE

Improper disposal of engine oil can be harmful to the environment. If you change your own oil, please dispose of used motor oil properly. Put it in a sealed container and take it to a recycling center. Do not throw it in the trash; do not pour it on the ground or down a drain.

4. With the engine in a level position, fill to the outer edge of the oil filler hole with the recommended oil (page 25).

OIL CAPACITY: 0.63 US quart (20.3 fl oz, 0.6 liter)

NOTICE

Running the engine with a low oil level can cause engine damage.

5. Screw in the oil filler cap/dipstick securely.

SERVICING YOUR SNOWTHROWER


Engine Oil Recommendations

Oil is a major factor affecting performance and service life. Use a high quality 4-stroke automotive detergent oil.

SAE 5W-30 is recommended for general use. Other viscosities

shown in the chart may be used when the average temperature in your area is within the indicated range. The SAE oil viscosity and service classification are on the API label on the oil container.


Honda recommends that you use API SERVICE category SJ (or later) oil or equivalent with the “starburst” certification mark displayed on the container.



SPARK PLUG SERVICE

To ensure proper engine operation, the spark plug must be properly gapped and free of deposits.

1. Open the spark plug access panel, then remove the spark plug cap. Use a commercially available spark plug wrench or socket to remove the spark plug.



SERVICING YOUR SNOWTHROWER

2. Inspect the spark plug. Replace it if the electrodes are worn or if the insulator is cracked, chipped, or fouled with deposits. Make sure that the spark plug washer is in good condition.

NOTICE


Use only the recommended spark plugs or equivalent. Spark plugs which have an improper heat range may cause engine damage.

A replacement spark plug may be purchased from a servicing Honda snowthrower dealer. See page 49 for a part number list.

SPARK PLUG: BPR5ES (NGK) or W16EPR-U (DENSO)

3. Measure the plug gap with a feeler gauge. Correct as necessary by bending the side electrode.

**PLUG GAP: 0.028 ~ 0.031 inch
(0.70 ~ 0.80 mm)**



4. Thread the spark plug in by hand to prevent cross-threading.
5. After the spark plug is seated, tighten with a spark plug wrench to compress the washer.

If installing a new spark plug, tighten 1/2 turn after the spark plug seats to compress the washer. If reinstalling a used spark plug, tighten 1/8 to 1/4 turn after the spark plug seats.

NOTICE

The spark plug must be securely tightened. An improperly tightened spark plug can become hot and may damage the engine.

6. Connect the spark plug cap.
7. Close the spark plug access panel.


SERVICING YOUR SNOWTHROWER

AUGER

Clutch Lever Free Play

Inspection

1. Move the clutch lever until you feel resistance from the cable. Measure the distance as shown.




CLUTCH LEVER DISTANCE:

7-1/2 ~ 8 inches
(190 ~ 205 mm)


Adjustment

1. Pull the spring cover up to expose the tension spring. Change the position of either the cable or spring on the metal plate so the clutch lever distance is correct.



Moving the spring makes a 1/4 inch (6 mm) change, while moving the cable makes a 3/8 inch (10 mm) change in the length of the cable.

2. Slide the cover back over the spring.





SERVICING YOUR SNOWTHROWER

Belt Tension

Inspection & Adjustment



1. Pull the spring cover up to expose the belt tension spring. Have a helper engage the auger clutch lever. Measure the length of the exposed coil as shown.
2. If the coil length is less than 78 mm, remove the z-bend fitting from the upper hole on the auger clutch lever, and install it into the lower hole. Recheck the spring length. If it is still less than 78 mm, check the auger clutch lever (page 27).



Auger Paddle Inspection

The paddles are thick, rubber parts bolted to the edges of the auger. The paddle are subject to wear, and should be inspected and replaced if worn beyond the service limit.

1. Park the snowblower on a flat, level surface. Disconnect the spark plug cap. Tilt the snowblower back enough to raise the auger housing.
2. Inspect the paddles on the auger and make sure they are in good condition and securely attached.
3. Measure the distance between the edge of the rubber paddle to the edge of the metal auger support.



AUGER PADDLE SERVICE LIMIT: 5/8 inch (15 mm)

Auger paddle replacement should only be done by a servicing Honda snowthrower dealer. If the paddles are worn out, the scraper bar may also need replacement (page 29).

SERVICING YOUR SNOWTHROWER


SCRAPER BLADE

The scraper blade wears with normal use and must be replaced when it reaches its service limit. The scraper blade thickness and adjustment determine the clearance between the rubber paddles and the ground.

Inspection


1. Turn the engine switch to the OFF position and disconnect the spark plug cap so the engine cannot be accidentally started.
2. Examine the scraper blade and verify it contacts the ground evenly. If it does not, adjust the scraper blade. See “Scraper blade adjustment” on page 30.

3. Measure the distance between the ground and lowest point on the rubber paddle on the auger. The paddle ground clearance should be $1/16 \sim 1/8$ inches ($1 \sim 3$ mm).



If the ground clearance is not within the specification, adjust the scraper blade. See “Scraper blade adjustment” on page 30.

4. Tilt the snowthrower back and measure the thickness of the scraper blade. Replace the scraper blade if it is less than $1/16$ inch (2 mm) thick. See “Scraper blade replacement” on page 30.




SERVICING YOUR SNOWTHROWER

Scraper blade adjustment

1. Tilt the snowblower forward to provide access the underside of the scraper blade.
2. Loosen (don't remove) the three flange nuts on the scraper blade.
3. Move the scraper blade down slightly. Tighten the self-locking nuts and recheck the clearance.


Repeat the procedure as needed to get the necessary clearance. If you cannot set the ground clearance within 1/8 ~ 1/16 inch, replace the scraper blade.



Scraper blade replacement

A new scraper blade can be purchased from a servicing Honda dealer. See page 49 for scraper blade and hardware part numbers.

1. Tilt the snowblower forward to provide access the underside of the scraper blade.
2. Remove the three flange nuts, flat washers, and the scraper blade.
3. Install the new scraper blade, reusing the bolts, washers, and nuts.
4. Adjust the scraper blade. See "Scraper blade adjustment" above.



STORAGE

STORAGE PREPARATION

Proper storage preparation is essential for keeping your snowthrower trouble-free and looking good. The following steps will help to keep rust and corrosion from impairing your snowthrower's function and appearance, and will make the engine easier to start when you use the snowthrower again.

Cleaning

1. Rinse the auger housing and wheels with a garden hose. Wipe the rest of the snowthrower with a moist rag.
2. After the snowthrower has dried, touch up any damaged paint.

Fuel

Gasoline will oxidize and deteriorate in storage. Old gasoline will cause hard starting, and it leaves gum deposits that clog the fuel system. If the gasoline in your engine deteriorates during storage, you may need to have the carburetor and other fuel system components serviced or replaced.

The length of time that gasoline can be left in your fuel tank and carburetor without causing functional problems will vary with such factors as gasoline blend, your storage temperatures, and whether the fuel tank is partially or completely filled. The air in a partially filled fuel tank promotes fuel deterioration. Very warm storage temperatures accelerate fuel deterioration. Fuel deterioration problems may occur within a few months, or even less if the gasoline was not fresh when you filled the fuel tank.

The *Distributor's Limited Warranty* does not cover fuel system damage or engine performance problems resulting from neglected storage preparation.

You can extend fuel storage life by adding a fuel stabilizer that is formulated for that purpose, or you can avoid fuel deterioration problems by draining the fuel tank and carburetor.

STORAGE


Adding a Fuel Stabilizer to Extend Fuel Storage Life

When adding a fuel stabilizer, fill the fuel tank with fresh gasoline. If only partially filled, air in the tank will promote fuel deterioration during storage. If you keep a container of gasoline for refueling, be sure that it contains only fresh gasoline. Add fuel stabilizer following the manufacturer's instructions.

After adding a fuel stabilizer, run the engine outdoors for 10 minutes to be sure that treated gasoline has replaced the untreated gasoline in the carburetor. Stop the engine, and move the fuel valve to the OFF position.

Draining the Fuel Tank and Carburetor

1. Place an approved gasoline container below the carburetor drain tube, and use a funnel to avoid spilling fuel. Turn the fuel valve to the ON position.
2. Insert a long, flat-tip screwdriver into the access hole on the left side. Locate the carburetor drain screw near the carburetor bowl. Loosen (don't remove) the drain screw until the fuel starts to drain. Drain until the fuel tank is empty, then tighten the drain screw.




⚠ WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Keep heat, sparks, and flames away.
- Handle fuel only outdoors.
- Wipe up spills immediately.


Engine Oil

1. Change the engine oil (page 24).
2. Remove the spark plug (page 25).
3. Pour a tablespoon (5 ~ 10 cc) of clean engine oil into the cylinder.
4. Pull the starter rope slowly several times to distribute the oil.
5. Reinstall the spark plug.
6. Pull the starter grip until resistance is felt. This will close the valves and protect the engine from internal corrosion.



Lubrication

Apply a few drops of oil or a small amount of grease to the following parts for lubrication and rust prevention.



STORAGE

STORAGE PRECAUTIONS

If your snowthrower will be stored with gasoline in the fuel tank and carburetor, it is important to reduce the hazard of gasoline vapor ignition. Select a well-ventilated storage area away from any appliance that operates with a flame, such as a furnace, water heater, or clothes dryer. Also avoid any area with a spark-producing electric motor, or where power tools are operated.

If possible, avoid storage areas with high humidity, because it promotes rust and corrosion.

Unless all fuel has been drained from the fuel tank, leave the fuel valve in the OFF position to reduce the possibility of fuel leakage.

Place the snowthrower on a level surface. Tilting can cause fuel or oil leakage.

With the engine and exhaust system cool, cover the snowthrower to keep out dust. A hot engine and exhaust system can ignite or melt some materials. Do not use sheet plastic as a dust cover. A nonporous cover will trap moisture around the engine, promoting rust and corrosion.

REMOVAL FROM STORAGE

Check your snowthrower as described in the *BEFORE OPERATION* chapter (page 11).

If the fuel was drained during storage preparation, fill the tank with fresh gasoline. If you keep a container of gasoline for refueling, be sure that it contains only fresh gasoline. Gasoline oxidizes and deteriorates over time, causing hard starting.

If the cylinder was coated with oil during storage preparation, the engine may smoke briefly at startup. This is normal.

TRANSPORTING

BEFORE LOADING

If the engine has been running, allow it to cool for at least 15 minutes before loading the snowthrower on the transport vehicle. A hot engine and exhaust system can burn you and can ignite some materials.

Turn the fuel valve to OFF. This will prevent carburetor flooding and reduce the possibility of fuel leakage.

Avoid removing any parts from the snowblower before transport, unless you are mechanically proficient, have the right tools, and follow the procedures in the *HS520 Shop Manual*.

LOADING AND UNLOADING

If a suitable loading ramp is not available, two people should lift the snowthrower on and off the transport vehicle while holding the snowthrower level.

Position the snowthrower so both wheels and the auger box are on the bed of the transport vehicle. Tie the snowthrower down with rope or straps, and block the wheels. Keep the tie-down rope or straps away from the auger drive clutch lever and cable.

TAKING CARE OF UNEXPECTED PROBLEMS

Electric starter does not operate

Possible cause	Correction
No electric power from the outlet.	Try a known good electrical outlet. Start the engine by using the recoil starter.
Defective power cord.	Try another power cord. Start the engine with the recoil starter.

Starter operates, but the engine will not start

Possible cause	Correction
Fuel valve is OFF.	Turn the fuel valve to ON (page 13).
Stale or old fuel.	Be sure the tank has fresh fuel. Drain the carburetor (page 32).
Spark plug cap is off.	Make sure the cap is connected.
Improper gap or deposits in the spark plug gap.	Verify the spark plug is free of deposits and has the proper gap (page 26).

TAKING CARE OF UNEXPECTED PROBLEMS

Engine has low power

Possible cause	Correction
Fast ground speed puts excessive load on the engine.	Reduce your walking speed.
Wet, deep snow puts an excessive load on the engine.	Reduce the snowthrowing swath.
Discharge chute is restricted.	Clear the discharge chute of obstructions (page 18).
Spark plug cap is not secure.	Make sure the spark plug cap is securely connected.
Improper electrode gap or deposits on the gap.	Verify the spark plug is free of deposits and has the proper gap (page 26).
Choke in the wrong position.	Make sure the choke is in the OPEN position (page 10).
Stale or old fuel.	Be sure the tank has fresh fuel. Drain the carburetor (page 32).

Engine runs, but snowthrower doesn't operate

Possible cause	Correction
Auger paddles are worn out.	Replace the auger paddles.
Auger clutch lever is not engaged.	Engage the auger clutch lever by pulling it toward the handlebar.
Drive clutch lever free play is excessive.	Adjust the free play (page 27).
Auger not engaging because the drive belt is worn, broken, or not on the pulleys.	See your servicing Honda snowthrower dealer.

TAKING CARE OF UNEXPECTED PROBLEMS

Snow not discharging properly

Possible cause	Correction
Discharge chute is restricted.	Clear the discharge chute of obstructions (page 18).
Foreign object stopping the auger from rotating.	Remove the foreign object.
Auger not engaging because the drive belt is worn, broken, or not on the pulleys.	See servicing Honda snowthrower dealer.
Swath is too wide for wet, deep snow conditions.	Reduce snowblowing swath.
Snowthrower is moving too fast for snow conditions.	Reduce your walking speed.

Engine stalls when the auger clutch lever is engaged

Possible cause	Correction
Discharge chute is restricted.	Clear the discharge chute and auger housing of obstructions (page 18).
Foreign object is stopping the auger from rotating.	
The auger is frozen.	

Tools Required

12 mm wrench, 10 mm wrench, and a Phillips screwdriver

Unpacking


1. Remove all the cardboard. Inspect the loose parts. Missing parts can be obtained from the Honda dealer who sold you the snowthrower.

Qty.	Description	Part number
4	Curved head bolt 8 x 40 mm	90109-VA4-000
4	Flange nut, 8 mm	94050-08000
4	Curved washer, 9 mm	90501-898-000
3	Phillips head shoulder screw 6 x 12 mm	90112-V10-000
3	Flange nut, 6 mm, Nylock	90303-V10-000
2	Cable tie (AS model only)	32901-VB5-A00
2	Key	35110-766-003

2. Loosen and remove the curved-head bolt, flange nut, and starter bracket from the lower handlebar. Do not discard the hardware.


Assembly

1. Install the handlebar with the hardware shown. Tighten the flange nuts securely.





SET-UP



2. Pull the clutch cable enough to insert the "Z" fitting on the cable through the auger clutch lever as shown here. Check the lever free play as shown on page 27.



3. Install the starter bracket using the hardware removed from step 2 on the previous page. For the HS520AS, snap the starter rope into the rope guide on the handlebar and install the two cable ties. Trim the cable ties to a length of 3/8 inch (10 mm).




4. Install the discharge chute using the three 6 mm Phillips-head screws and 6 mm self-locking nuts. Make sure the screws go on the inside and the nuts on the outside. **Tighten the nuts securely: HEX NUT TORQUE: 7 ft-lbs (10 N•m)**



5. Lift the spark plug door and attach the spark plug wire to the spark plug.
6. Remove any packing material from the side of the snowthrower.

Add Oil & Fuel

1. The snowthrower is shipped **WITHOUT OIL** in the engine.
2. Add enough of the recommended oil (page 25) to bring the oil level to the top of the filler hole.
3. Add regular unleaded fuel to the fuel tank. The fuel capacity is 0.3 US gallons (1.3 liters). See pages 22 and 44.



Before Use

All operators of the snowthrower must read the *SNOWTHROWER SAFETY* (page 4), *CONTROLS & FEATURES* (page 8), and *BEFORE OPERATION* (page 11) before using the snowthrower.



TECHNICAL & CONSUMER INFORMATION

TECHNICAL INFORMATION

Serial Number Locations

Record the engine and frame serial numbers in the spaces below. You may need these serial numbers when ordering parts, and when making technical or warranty inquiries (page 55).

ENGINE SERIAL NUMBER
Use a flashlight to view through the hole for the exhaust pipe. The number starts with "GC..."



FRAME SERIAL NUMBER

Engine serial number: _____

Frame serial number: _____

Date of purchase: _____

Carburetor Modification for High Altitude Operation

At high altitude, the standard carburetor air-fuel mixture will be too rich. Performance will decrease, and fuel consumption will increase. A very rich mixture will also foul the spark plug and cause hard starting. Operation at an altitude that differs from that at which this engine was certified, for extended periods of time, may increase emissions.

High altitude performance can be improved by specific modifications to the carburetor. If you always operate your snowthrower at altitudes above 5,000 feet (1,500 meters), have your servicing dealer perform this carburetor modification. This engine, when operated at high altitude with the carburetor modifications for high altitude use, will meet each emission standard throughout its useful life.

Even with carburetor modification, engine horsepower will decrease about 3.5% for each 1,000-foot (300-meter) increase in altitude. The effect of altitude on horsepower will be greater than this if no carburetor modification is made.

NOTICE

When the carburetor has been modified for high altitude operation, the air-fuel mixture will be too lean for low altitude use. Operation at altitudes below 5,000 feet (1,500 meters) with a modified carburetor may cause the engine to overheat and result in serious engine damage. For use at low altitudes, have your servicing dealer return the carburetor to original factory specifications.

TECHNICAL & CONSUMER INFORMATION

Oxygenated Fuels

Some conventional gasolines are being blended with alcohol or an ether compound. These gasolines are collectively referred to as oxygenated fuels. To meet clean air standards, some areas of the United States and Canada use oxygenated fuels to help reduce emissions.

If you use an oxygenated fuel, be sure it is unleaded and meets the minimum octane rating requirement.

Before using an oxygenated fuel, try to confirm the fuel's contents. Some states/provinces require this information to be posted on the pump.

The following are the EPA-approved percentages of oxygenates:

ETHANOL — (ethyl or grain alcohol) 10% by volume

You may use gasoline containing up to 10% ethanol by volume. Gasoline containing ethanol may be marketed under the name "Gasohol".

MTBE — (Methyl Tertiary Butyl Ether) 15% by volume

You may use gasoline containing up to 15% MTBE by volume.

METHANOL — (methyl or wood alcohol) 5% by volume

You may use gasoline containing up to 5% methanol by volume, as long as it also contains cosolvents and corrosion inhibitors to protect the fuel system.

Gasoline containing more than 5% methanol by volume may cause starting and/or performance problems. It may also damage metal, rubber, and plastic parts of your fuel system.

Fuel system damage or performance problems resulting from the use of an oxygenated fuel containing more than the percentages of oxygenates mentioned above are not covered under warranty.

EMISSION CONTROL SYSTEM

Source of Emissions

The combustion process produces carbon monoxide, oxides of nitrogen, and hydrocarbons. Control of hydrocarbons and oxides of nitrogen is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda uses lean carburetor settings and other systems to reduce the emissions of carbon monoxide, oxides of nitrogen, and hydrocarbons.

The U.S., California Clean Air Act and Environment Canada

EPA, California and Canadian regulations require all manufacturers to furnish written instruction describing the operation and maintenance of emission control systems.

The following instructions and procedures must be followed in order to keep the Honda engine emissions within the emission standards.

Tampering and Altering

Tampering with or altering the emission control system may increase emissions beyond the legal limit. Some acts that constitute tampering:

- Removal or alteration of any part of intake, fuel, or exhaust system.
- Altering or defeating the governor linkage or speed-adjusting mechanism to cause the engine to operate outside its design parameters.

Problems That May Affect Emissions

If you are aware of any of the following symptoms, have your engine inspected and repaired by your authorized Honda servicing dealer.

- Hard starting or stalling after starting
- Rough idle
- Misfiring or backfiring under load
- Afterburning (backfiring)
- Black exhaust smoke or high fuel consumption

TECHNICAL & CONSUMER INFORMATION

Replacement Parts

The emission control systems on your new Honda engine were designed, built, and certified to conform with EPA, California and Canadian emission regulations. We recommend the use of genuine Honda parts whenever you have maintenance done. These original-design replacement parts are manufactured to the same standards as the original parts, so you can be confident of their performance. The use of replacement parts that are not of the original design and quality may impair the effectiveness of your emission control system.

A manufacturer of an aftermarket part assumes the responsibility the part will not adversely affect emission performance. The manufacturer or rebuilder of the part must certify that use of the part will not result in a failure of the engine to comply with emission regulations.

Maintenance

Follow the *Maintenance Schedule* on page 21. Remember that this schedule is based on the assumption that your machine will be used for its designed purpose. Sustained high-load operation will require more frequent service.

TECHNICAL & CONSUMER INFORMATION

Air Index

An Air Index Information hang tag/label is applied to engines certified to an emission durability time period in accordance with the requirements of the California Air Resources Board.

The bar graph is intended to provide you, our customer, the ability to compare the emissions performance of available engines. The lower the Air Index, the less pollution.

The durability description is intended to provide you with information relating the engine's emission durability period. The descriptive term indicates the useful life period for the engine's emission control system. See your *Emission Control System Warranty* (page 52) for additional information.

Descriptive Term	Applicable to Emissions Durability Period
Moderate	50 hours (0–65 cc) 125 hours (greater than 65 cc)
Intermediate	125 hours (0–65 cc) 250 hours (greater than 65 cc)
Extended	300 hours (0–65 cc) 500 hours (greater than 65 cc)

The Air Index Information hang tag/label must remain on the snowthrower until it is sold. Remove the hang tag before operating the snowthrower.

TECHNICAL & CONSUMER INFORMATION

SPECIFICATIONS

Frame	
Description code	SZBG
Length	49.5 inches (1258 mm)
Width	20.7 inches (527 mm)
Height	40.4 inches (1026 mm)
Dry weight	HS520A: 82 lbs (37 kg) HS520AS: 88 lbs (40 kg)
Snow clearance (h x w)	12 x 20 inches (306 x 500 mm)
Max. snowthrowing distance (varies with conditions and snow)	front: 26 feet (8 m) left/right: 16 feet (5 m)
Continuous operating time	1.6 hours
Clearing capacity	55 tons/hour (50 metric tons/hour)
Noise level	84.4 dB(A)

Engine	
Model	GC160
Maximum output	5.0 hp @ 3,600 rpm
Displacement	9.8 cubic inches (161 cc)
Bore x stroke	2.5 x 2.0 inches (64 x 50 mm)
Starting method	HS520: recoil (pull start) HS520AS recoil or AC electric
Ignition system	Transistorized magneto
Oil capacity	0.63 US quart (20.3 fl oz, 0.6 liter)
Fuel tank capacity	0.3 US gallon (1.3 liters)
Spark plug	NGK: BPR5ES or DENSO: W16EPR-U

Tuneup	
Spark plug gap	0.028 ~ 0.031 in (0.70 ~ 0.80 mm)
Valve clearance	intake: 0.15 mm exhaust: 0.20 mm
Other specifications	No other adjustments needed

Specifications are subject to change without notice.

TECHNICAL & CONSUMER INFORMATION

CONSUMER INFORMATION

Dealer Locator Information

To find an Authorized Honda Servicing Dealer anywhere in the United States:

Call (800) 426-7701

or visit our website: www.hondapowerequipment.com and click Dealer Locator.

Customer Service

See page 55.

Honda Publications

These publications will give you additional information for maintaining and repairing your snowthrower.

Shop Manual

This manual covers complete maintenance and overhaul procedures. It is intended to be used by a skilled technician. It is available through your Honda dealer or through Helm Inc. at 1 888-292-5395 or visit www.hondapowerequipment.com and click Product Manuals.

Parts Catalog

This manual provides complete, illustrated parts lists, and is available through your Honda dealer.

Replacement Parts

Listed here are some common replacement parts. Contact a servicing Honda snowthrower dealer to purchase them.

Item	Part Number
Spark plug	98079-55846 (NGK)
Scraper blade	76322-V10-020
Scraper blade nut, 8 mm	90309-428-731
Scraper blade washer, 8.5 mm	90521-259-000

TECHNICAL & CONSUMER INFORMATION

Distributor's Limited Warranty

PRODUCTS COVERED BY THIS WARRANTY	LENGTH OF WARRANTY (from date of original retail purchase)	
	Noncommercial/Nonrental	Commercial/Rental
Snowthrower	24 months	3 months

To Qualify for this Warranty:

The product must be purchased in the United States, Puerto Rico, or the U.S. Virgin Islands from American Honda or a dealer authorized by American Honda to sell those products. This warranty applies to the first retail purchaser and each subsequent owner during the applicable warranty time period.

What American Honda will Repair or Replace Under Warranty:

American Honda will repair or replace, at its option, any part that is proven to be defective in material or workmanship under normal use during the applicable warranty time period. Warranty repairs and replacements will be made without charge for parts or labor. Anything replaced under warranty becomes the property of American Honda Motor Company, Inc. All parts replaced under warranty will be considered as part of the original product and any warranty on those parts will expire coincident with the original product warranty.

To Obtain Warranty Service:

You must take the Honda snowthrower and proof of original retail purchase date, at your expense, to any Honda Power Equipment dealer in the United States, Puerto Rico, or the U.S. Virgin Islands who is authorized to service that product, during the dealer's normal business hours. If you are unable to obtain warranty service, or are dissatisfied with the warranty service you receive, take the following steps: First, contact the owner of the dealership involved; normally this should resolve the problem. However, if you should require further assistance, write or call the Power Equipment Customer Relations Department of American Honda Motor Co., Inc. Refer to page 55 for contact information.

Exclusions:

THIS WARRANTY DOES NOT EXTEND TO PARTS AFFECTED OR DAMAGED BY ACCIDENT AND/OR COLLISION, NORMAL WEAR, FUEL CONTAMINATION, USE IN AN APPLICATION FOR WHICH THE PRODUCT WAS NOT DESIGNED, OR ANY OTHER MISUSE, NEGLIGENCE, INCORPORATION OR USE OF UNSUITABLE ATTACHMENTS OR PARTS, UNAUTHORIZED ALTERATION, OR ANY CAUSES OTHER THAN DEFECTS IN MATERIAL OR WORKMANSHIP OF THE PRODUCT.

THE AUGER AND PADDLE ASSEMBLIES OF SNOWTHROWERS ARE SPECIFICALLY NOT WARRANTED AGAINST DAMAGE, INCLUDING BUT NOT LIMITED TO, ABRASIVE DAMAGE.

Disclaimer of Consequential Damage and Limitation of Implied Warranties: AMERICAN HONDA DISCLAIMS ANY RESPONSIBILITY FOR LOSS OF TIME OR USE OF THE PRODUCT, TRANSPORTATION, COMMERCIAL LOSS, OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGE. ANY IMPLIED WARRANTIES ARE LIMITED TO THE DURATION OF THIS WRITTEN LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusions and limitations may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

TECHNICAL & CONSUMER INFORMATION

Accessories, Replacement Parts, and Apparel Warranty

PRODUCTS COVERED BY THIS WARRANTY	LENGTH OF WARRANTY (from date of original retail purchase)	
	Noncommercial/Nonrental	Commercial/Rental
Accessories	12 months	3 months
Replacement Parts	6 months	3 months
Apparel	6 months	3 months

To Qualify for this Warranty:

1. The accessories, replacement parts, or apparel must be purchased in the United States, Puerto Rico, or the U.S. Virgin Islands from American Honda or a dealer authorized by American Honda to sell those products.
2. You must be the first retail purchaser. This warranty is not transferable to subsequent owners.

What American Honda will Repair or Replace Under Warranty:

American Honda will repair or replace, at its option, any power equipment accessories, replacement parts, or apparel that are proven to be defective in material or workmanship under normal use during the applicable warranty time period. Anything replaced under warranty becomes the property of American Honda Motor Company, Inc. All parts replaced under warranty will be considered as part of the original product and any warranty on those parts will expire coincident with the original product warranty.

Accessories and replacement parts, installed by a dealer who is authorized by American Honda to sell them, will be repaired or replaced under warranty without charge for parts or labor. If installed by anyone else, accessories and replacement parts will be repaired or replaced under warranty without charge for parts, but any labor charges will be the responsibility of the purchaser. Apparel will be repaired or replaced under warranty without any charge.

To Obtain Warranty Service:

You must take the Honda Power Equipment accessory, replacement part, apparel or the power equipment on which the accessory or replacement part is installed, and proof of purchase, at your expense, to any Honda Power Equipment dealer in the United States, Puerto Rico, or the U.S. Virgin Islands who is authorized to service that product, during the dealer's normal business hours. If you are unable to obtain warranty service, or are dissatisfied with the warranty service you receive, take the following steps: First, contact the owner of the dealership involved; normally this will resolve the problem. However, if you should require further assistance, write or call the Power Equipment Customer Relations Department of American Honda Motor Co., Inc. Refer to page 55 for contact information.

Exclusions:

THIS WARRANTY DOES NOT EXTEND TO ACCESSORIES, PARTS, OR APPAREL AFFECTED OR DAMAGED BY ACCIDENT AND/OR COLLISION, NORMAL WEAR, USE IN AN APPLICATION FOR WHICH THE PRODUCT WAS NOT DESIGNED, OR ANY OTHER MISUSE, NEGLIGENCE, INCORPORATION OR USE OF UNSUITABLE ATTACHMENTS OR PARTS, UNAUTHORIZED ALTERATION, IMPROPER INSTALLATION, OR ANY CAUSES OTHER THAN DEFECTS IN MATERIAL OR WORKMANSHIP OF THE PRODUCT.

THE AUGER AND PADDLE ASSEMBLIES OF SNOWTHROWERS ARE SPECIFICALLY NOT WARRANTED AGAINST DAMAGE, INCLUDING BUT NOT LIMITED TO, ABRASIVE DAMAGE.

Disclaimer of Consequential Damage and Limitation of Implied Warranties:

AMERICAN HONDA DISCLAIMS ANY RESPONSIBILITY FOR LOSS OF TIME OR USE OF THE PRODUCT, OR THE POWER EQUIPMENT ON WHICH THE PRODUCT IS INSTALLED, TRANSPORTATION, COMMERCIAL LOSS, OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGE. ANY IMPLIED WARRANTIES ARE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusions and limitations may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

TECHNICAL & CONSUMER INFORMATION

Emission Control System Warranty

Your new Honda Power Equipment engine complies with the U.S. EPA, Environment Canada and State of California emission regulations. American Honda Motor Co., Inc. provides the emission warranty coverage for engines in the United States, and its territories. Honda Canada Inc. provides the emission warranty for engines in the 13 provinces and territories of Canada. In the remainder of this Emission Control System Warranty, American Honda Motor Company Inc. and Honda Canada Inc. will be referred to as Honda.

Your Warranty Rights And Obligations:

California

The California Air Resources Board and Honda are pleased to explain the emission control system warranty on your Honda Power Equipment engine. In California, new spark-ignited small off-road equipment engines must be designed, built and equipped to meet the State's stringent anti-smog standards.

Other States, U.S. territories and Canada

In other areas of the United States and in Canada, your engine must be designed, built, and equipped to meet the U.S. EPA and Environment Canada emission standards for spark-ignited engines at or below 19 kilowatts.

All of the United States and Canada

Honda must warrant the emission control system on your power equipment engine for the period of time listed below, provided there has been no abuse, neglect or improper maintenance of your power equipment engine. Where a warrantable condition exists, Honda will repair your power equipment engine at no cost to you including diagnosis, parts and labor.

Your emission control system may include such parts as the carburetor or fuel injection system, the ignition system, and catalytic converter. Also included may be hoses, connectors and other emission-related assemblies.

Manufacturer's Warranty Coverage:

The 1995 and later power equipment engines are warranted for two years. If any emission-related part on your engine is defective, the part will be repaired or replaced by Honda.

Owner's Warranty Responsibility:

As the power equipment engine owner, you are responsible for the performance of the required maintenance listed in your owner's manual. Honda recommends that you retain all receipts covering maintenance on your power equipment engine, but Honda cannot deny warranty coverage solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

As the power equipment engine owner, you should however be aware Honda may deny you warranty coverage if your power equipment engine or a part has failed due to abuse, neglect, improper maintenance, or unapproved modifications.

You are responsible for presenting your power equipment engine to a Honda Power Equipment dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

TECHNICAL & CONSUMER INFORMATION

If you have any questions regarding your warranty rights and responsibilities, you should contact the Honda Office in your region:

American Honda Motor Co., Inc.
Power Equipment Customer Relations
4900 Marconi Drive
Alpharetta, Georgia 30005-8847
Telephone: (770) 497-6400

or

Honda Canada Inc.
Power Equipment Customer Relations
715 Milner Avenue
Toronto, ON M1B 2K8
Telephone: (888) 946-6329

Warranty Coverage:

Honda power equipment engines manufactured after January 1, 1995 and sold in the State of California, U.S. EPA certified engines manufactured on or after September 1, 1996 and sold in all of the United States, and Canadian certified engines manufactured on or after January 1, 2005 are covered by this warranty for a period of two years from the date of delivery to the original retail purchaser. This warranty is transferable to each subsequent purchaser for the duration of the warranty period.

Warranty repairs will be made without charge for diagnosis, parts or labor. All defective parts replaced under this warranty become the property of Honda. Warranted parts are listed under *Emission Control System Warranty Parts* later on this page. Normal maintenance items, such as spark plugs and filters, that are on the warranted parts list are warranted up to their required replacement interval only.

Honda is also liable for damages to other engine components caused by a failure of any warranted part during the warranty period.

Only Honda approved replacement parts may be used in the performance of any warranty repairs and must be provided without charge to the owner. The use of replacement parts not equivalent to the original parts may impair the effectiveness of your engine emission control system. If such a replacement part is used in the repair or maintenance of your engine, and an authorized Honda dealer determines it is defective or causes a failure of a warranted part, your claim for repair of your engine may be denied. If the part in question is not related to the reason your engine requires repair, your claim will not be denied.

To Obtain Warranty Service:

You must take your Honda Power Equipment engine or the product on which it is installed, along with your sales registration card or other proof of original purchase date, at your expense, to any Honda Power Equipment dealer who is authorized by Honda to sell and service that Honda product during his normal business hours. Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine was not properly maintained and used.

If you are unable to obtain warranty service, or are dissatisfied with the warranty service you received, contact the owner of the dealership involved. Normally this should resolve your problem. However, if you require further assistance, write or call the Honda Power Equipment Customer Relations Department in your region.

TECHNICAL & CONSUMER INFORMATION

Exclusions:

FAILURES OTHER THAN THOSE RESULTING FROM DEFECTS IN MATERIAL OR WORKMANSHIP ARE NOT COVERED BY THIS WARRANTY. THIS WARRANTY DOES NOT EXTEND TO EMISSION CONTROL SYSTEMS OR PARTS WHICH ARE AFFECTED OR DAMAGED BY OWNER ABUSE, NEGLIGENCE, IMPROPER MAINTENANCE, MISUSE, MISFUELING, IMPROPER STORAGE, ACCIDENT AND/OR COLLISION, THE INCORPORATION OF, OR ANY USE OF, ANY ADD-ON OR MODIFIED PARTS, UNSUITABLE ATTACHMENTS, OR THE UNAUTHORIZED ALTERATION OF ANY PART.

THIS WARRANTY DOES NOT COVER REPLACEMENT OF EXPENDABLE MAINTENANCE ITEMS MADE IN CONNECTION WITH REQUIRED MAINTENANCE SERVICES AFTER THE ITEM'S FIRST SCHEDULED REPLACEMENT AS LISTED IN THE MAINTENANCE SECTION OF THE PRODUCT OWNER'S MANUAL, SUCH AS: SPARK PLUGS AND FILTERS.

Disclaimer of Consequential Damage and Limitation of Implied Warranties:

AMERICAN HONDA MOTOR CO., INC. AND HONDA CANADA INC. DISCLAIM ANY RESPONSIBILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES SUCH AS LOSS OF TIME OR THE USE OF THE POWER EQUIPMENT, OR ANY COMMERCIAL LOSS DUE TO THE FAILURE OF THE EQUIPMENT; AND ANY IMPLIED WARRANTIES ARE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. THIS WARRANTY IS APPLICABLE ONLY WHERE THE CALIFORNIA, U.S. EPA OR ENVIRONMENT CANADA EMISSION CONTROL SYSTEM WARRANTY REGULATION IS IN EFFECT.

Emission Control System Warranty Parts:

SYSTEMS COVERED BY THIS WARRANTY:	PARTS DESCRIPTION:
Fuel Metering	Carburetor assembly, Fuel injection pump, Fuel injection nozzle, Fuel regulator, Intake manifold
Exhaust	Catalyst
Air Induction	Air filter housing, Air filter element*, Crankcase breather tube
Ignition	Flywheel magneto, Ignition pulse generator, Ignition coil assembly, Ignition control module, Spark plug cap, Spark plug*
Miscellaneous Parts	Tubing, fittings, seals, gaskets, and clamps associated with these listed systems.

* Covered up to the first required replacement only. See the Maintenance Schedule on page 21.

TECHNICAL & CONSUMER INFORMATION

Customer Service Information

Honda Power Equipment dealership personnel are trained professionals. They should be able to answer any question you may have. If you encounter a problem that your dealer does not solve to your satisfaction, please discuss it with the dealership's management. The Service Manager or General Manager can help. Almost all problems are solved in this way.

If you are dissatisfied with the decision made by the dealership's management, contact the Honda Power Equipment Customer Relations Office. You can write:

American Honda Motor Co., Inc.
Power Equipment Division
Customer Relations Office
4900 Marconi Drive
Alpharetta, GA 30005-8847

Or telephone: (770) 497-6400 M-F, 8:30 a.m. - 8:00 p.m. EST

When you write or call, please give us this information:

- Model and serial numbers (page 42)
- Name of the dealer who sold the snowthrower to you
- Name and address of the dealer who services your snowthrower
- Date of purchase
- Your name, address, and telephone number
- A detailed description of the problem

INDEX

A

- Air index 47
- Altitude, modifications for .. 43
- Assembly 39
- auger
 - paddle service limit 28
- auger clutch lever
 - adjustment 27

C

- Carburetor
 - Draining 32
 - Modifications for altitude 43
- Control locations 8
- Customer relations 55

D

- Drive problems 37

E

- Emissions
 - Control 45
 - Warranty 52

F

- Fuel
 - Capacity 22
 - Oxygenated 44
 - Recommendations 23
 - Refueling 22
 - Storage information 31
- Fuel tank draining 32

H

- High altitude modifications .. 43

I

- Introduction 1

L

- Loading 35

M

- Maintenance schedule 21

N

- Notice symbol 1

O

- Oil
 - Capacity 24
 - Change 24
 - Check level 23
 - Recommended 25
 - Storage information 33

P

- Parts
 - Catalog 49
 - List 49
- Problems 36
- Publications 49

S

- Safety
 - A few words 2
 - Important information ... 4
 - Label description 2
 - Label locations 4
 - Maintenance 20
 - Messages 2
- Scraper blade
 - Adjustment 29
 - Inspection 29
- Serial number locations ... 42
- Set-up 39
- Shop manual 49
- Spark knock 23
- Spark plug
 - Gap 26
 - Recommended type ... 26
 - Service 25
- Specifications 48
- Storage
 - Cleaning 31
 - Fuel 31
 - Precautions 34

T

- Transporting 35
- Troubleshooting 37

U

- Unloading 35

W

- Warranty
 - Accessories and parts . . . 51
 - Emissions 52
 - Getting service 55
 - Snowthrower 50

QUICK REFERENCE INFORMATION

Fuel	Type	Unleaded gasoline with a pump octane rating of 86 or higher (page 23)
	Capacity	0.3 US gal (1.3 ℓ)
Engine oil	Type	Above 15°F (-9°C): SAE 5W-30 Below 15°F (-9°C): SAE 0W-30 API SJ or later (page 25)
	Capacity	0.63 US qt (20.3 fl oz, 0.6 ℓ)
Spark plug	Type	Regular: NGK BP5ES DENSO W16EP-U Resistor: NGK BPR5ES DENSO W16EPR-U
	Electrode gap	0.028 – 0.031 in (0.70 – 0.80 mm)
Maintenance	Before each use/ subsequent	Refer to the Maintenance Schedule (page 21)

HONDA

The Power of Dreams

31V10610
00X31-V10-6100



Printed on
Recycled Paper

EM3

HS520A
HS520K1AS
POM53091-C

IPC 5500.2005.07
PRINTED IN U.S.A.