

SOLOS<sup>T.M.</sup>

CUTER<sup>T.M.</sup>

USER'S MANUAL



Processor Technology Corp.  
6200 Hollis St.  
Emeryville, CA 94608  
(415) 652-8080



Software Technology Corporation  
P.O. Box 5260  
San Mateo, CA 94402  
(415) 349-8080

M0100

SOLOS<sup>(tm)</sup> / CUTER<sup>(tm)</sup>

USER'S MANUAL

PROCESSOR TECHNOLOGY CORP.  
6200 Hollis Street  
Emeryville, CA 94608

(415) 652-8080

SOFTWARE TECHNOLOGY CORP.  
P. O. Box 5260  
San Mateo, CA 94402

(415) 349-8080

(C) 1977 by Processor Technology Corporation

I M P O R T A N T   N O T I C E

This copyrighted software product is distributed on an individual sale basis for the personal use of the original purchaser only. No license is granted herein to copy, duplicate, sell or otherwise distribute to any other person, firm or entity. This software product is copyrighted and all rights are reserved.

S O F T W A R E   W A R R A N T Y

Software Technology Corporation warrants this Software Product to be free from defects in material and workmanship for a period of three months from the date of original purchase.

This warranty is made in lieu of any other warranty expressed or implied and is limited to repair or replacement, at the option of Software Technology Corporation, transportation and handling charges excluded.

To obtain service under the terms of this warranty, the defective part must be returned, along with a copy of the original bill of sale, to Software Technology Corporation within the warranty period.

The warranty herein extends only to the original purchaser and is not assignable or transferable and shall not apply to any software product which has been repaired by anyone other than Software Technology Corporation or which may have been subject to alterations, misuse, negligence, or accident, or any unit which may have had the name altered, defaced or removed.

## P R E F A C E

This manual describes the use and operation of either SOLOS<sup>(tm)</sup> or CUTER<sup>(tm)</sup>. SOLOS is a program designed to be a personality module in a Sol<sup>(tm)</sup>. CUTER is a program designed to provide much of the power of SOLOS for the non-Sol user. Because SOLOS and CUTER have been designed to be compatible operating systems, this manual will refer to SOLOS meaning the SOLOS/CUTER operating system. The few differences between SOLOS and CUTER will be stated explicitly.

<sup>(tm)</sup> SOLOS, CUTER and Sol are trademarks of Processor Technology Corporation.

SOLOS/CUTER User's Manual

TABLE OF CONTENTS

I. INTRODUCTION	
Definition of Terms	1
Quick Command Reference List	2
II. CONSOLE COMMANDS	
Console Commands in Brief	4
Console Commands in Detail	
Execute Command	4
Enter Command	4
Dump Command	4
Terminal Command	5
Custom Command	5
III. TAPE COMMANDS	
Tape Commands in Brief	6
Tape Commands in Detail	
Get a File from Tape into Memory	7
Get, then Execute	7
Save a File	7
Catalog a File	7
IV. SET COMMANDS	
SOLOS' Ten Set Commands	9
Set Commands in Detail	
Set Speed of Display	9
Input/Output Commands	9
Set Out Command	9
Set In Command	10
Set Tape Command	10
Set Type Command	11
Set Execute Command	11
Custom Input/Output Commands	11

SOLOS/CUTER User's Manual

TABLE OF CONTENTS (cont.)

IV. SET COMMANDS (cont.)

Set CRC Error Checking Command	12
Set Number of NULLS Command	12

V. SUBROUTINES

A. Introduction to SOLOS Machine Language Interface	14
Pseudo Ports for SOLOS	14
Pseudo Ports for CUTER	14
Defined Register Usages	15
SOLOS Jump Table - Defined	15
Jump Table	16
B. System Entry Points	17
C. SOLOS Input Entry Points	
SINP	17
AINP	17
D. SOLOS Output Entry Points	
SOUT	17
AOUT	18
E. SOLOS VDM Display Driver	18
F. Cassette Tape Entry Points to SOLOS	19
File Header	19
Block Access	20
Read Tape Block Routine	20
Write Tape Block Routine	21
Byte Access	21
File Open Routine	22
Write Byte Routine	22
Read Byte Routine	23
Close File Routine	23

VI. LOADING & EXECUTING CUTER	24
-------------------------------	----

## I. INTRODUCTION

SOLOS is a 2048 byte program that configures the Sol-20 and one or two cassette tape recorders into a powerful, stand-alone computing system. SOLOS takes advantage of the Sol-20's built-in hardware peripherals and the 8080 instruction set to optimize the convenience and power of the inherent computer capabilities of the Sol.

Outstanding features of SOLOS include...

- **STANDARDIZED I/O SOFTWARE PROTOCOL** which makes all Sol-20 I/O (keyboard, display, serial, parallel and cassette) accessible to external programs from one entry point--a standard feature in all future Sol system software products that will require less memory than would normally be used for I/O routines.
- **SOFTWARE INTERFACE** permits user defined routines for custom applications.
- **"INDUSTRY STANDARD-SETTING" CASSETTE I/O CONTROL** includes methods for loading and saving programs and commands that execute programs after automatic loading.
- **EXCLUSIVE CASSETTE I/O ROUTINES** allow cassette files to be accessed on a byte-by-byte basis as though each file were a byte-by-byte device. Thus, data transfer to and from cassettes appears as normal I/O--and two cassettes can be used simultaneously to assemble and edit programs.
- **NEW DISPLAY CONTROL** features found only in expensive video terminals--including ESCAPE sequences for cursor positioning and character speed control.
- **19 COMMANDS** to access the basic requirements of the Sol-20 control cassette tape recorders and set up special conditions in SOLOS. (See the "Quick Command Reference List".)

### Definition of Terms

In this manual:

addr means word address hexadecimal characters, (0-FFFF) range

data means hexadecimal characters, (0-FF) range

file means a collection of data

name means any one to five character identification for a file

port means a SOLOS pseudoport from 0 to 3

unit means a number of 1 or 2 corresponding to the appropriate tape recorder

( ) means optional parameters

I. INTRODUCTION (cont.)

Only the first two letters of the command expressions must be typed when entering a command expression. (The underscored letters in the following Quick Command Reference List.)

Quick Command Reference List

COMMAND	FUNCTION
<u>Console</u>	
<u>EXEC</u> addr	Begin program execution at 'addr'
<u>ENTR</u> addr	Enter data into memory starting at 'addr'
<u>DUMP</u> addr1 (addr2)	Dump memory data, 'addr1' to 'addr2'
<u>TERM</u> (portin (portout))	Enter Terminal Mode
<u>CUST</u> name (addr)	Insert or remove a custom command
<u>Tape</u>	
<u>GET</u> (name(/unit) (addr))	Get a tape file into memory
<u>SAVE</u> name (/unit) addr1 addr2 (addr3)	Save a file from memory to tape
<u>XEQ</u> (name(/unit) (addr))	Get then execute a tape file
<u>CAT</u> (/unit)	Catalog tape files
<u>Set</u>	
<u>SET</u> <u>S</u> =data	Screen character rate
<u>SET</u> <u>I</u> =port	Input port to SOLOS
<u>SET</u> <u>O</u> =port	Output port to SOLOS
<u>SET</u> <u>N</u> =data	Number of NULLS following CRLF
<u>SET</u> <u>XEQ</u> addr	Auto-execute addr
<u>SET</u> <u>TAPE</u> 0 or 1	0=1200 baud, 1=300 baud
<u>SET</u> <u>TYPE</u> data	Type 'byte' header
<u>SET</u> <u>COUT</u> addr	Custom output addr
<u>SET</u> <u>CIN</u> addr	Custom input addr
<u>SET</u> <u>CRC</u> data	Allows ignoring of tape CRC Read Errors



I. INTRODUCTION (cont.)

With a Sol, or CUTER on a Processor Technology GPM board, a power-on performs a reset which causes a SOLOS system reset. The Sol user may initiate this system reset anytime by simultaneously pressing the upper case and repeat keys.

A SOLOS system reset enters SOLOS into COMMAND mode. When in COMMAND mode, SOLOS will do a Carriage Return-Line Feed (CRLF) followed by a prompt (>). SOLOS then awaits the entry of a COMMAND. A COMMAND is processed upon receipt of a Carriage Return (CR). Pressing the MODE (or Control-@) key while awaiting a COMMAND causes the current COMMAND input line to be ignored and return to COMMAND mode. CUTER also resets the current I/O pseudo port selections to the system default.

The MODE (or Control-@) key is also used to abort the execution of most commands. This use of the MODE (or Control-@) key turns off both tape machines (if on) and returns to COMMAND mode.

## II. CONSOLE COMMANDS

### Console Commands in Brief

SOLOS has five console commands. They are:

<u>Command</u>	<u>Function</u>
<u>EXEC</u> addr	Begin program execution at 'addr'.
<u>ENTR</u> addr	Enter data into memory starting at 'addr'.
<u>DUMP</u> addr1 (addr2)	Dump memory data, 'addr1' to 1addr2'.
<u>TERM</u> (portin (portout))	Enter Terminal Mode (available under SOLOS only)
<u>CUST</u> name (addr)	Insert or remove a custom command.

### Console Commands in Detail

#### Execute Command      EXEC addr

This command begins program execution at memory location specified by (addr).

Example:      EXEC 2000

#### Enter Command      ENTR addr

Example:      ENTR 5000  
                  : C3 00 01 1000: 05/

Result:      Beginning at memory location 5000, the following data was entered: C3 00 01. The new memory location of 1000: was selected to enter the data 51. The slash (/) terminated the ENTR command and returned to command mode.

#### Dump Command      DUMP addr1 (addr2)

This command displays sequential memory data on the screen starting at location (addr1) and ending with (addr2).

Example:      DUMP C02E C037

Result:      C02E E1 DB FA 2F E6 01 C8 DB FC C9

Dumped the SOLOS keyboard input routine.  
(See listing.) Starting at memory location C02E and ending at memory location C037.

II. CONSOLE COMMANDS (cont.)

Terminal Command      TERM (port-I (port-0)) (Available under SOLOS only)

This command causes the Sol system to become a video terminal for connection to an external computer or modem. This command begins by automatically setting the I/O pseudo ports to the specified values. An omitted port parameter will be set to 1. Execution then proceeds by sending all Sol keyboard entries (except cursor control) to the specified Output pseudo port. Any input available from the Input pseudo port will be processed by the SOLOS display driver.

Example:    TERM

Result:    Keyboard data will be sent to the serial port and all data from the serial port will appear on the display screen.

Custom Command      CUST name (addr)      definition/removal

When a non-SOLOS command is entered, a separate table of custom commands (in RAM) will be searched. The CUST command is used to enter and remove up to six custom command names from the custom command table. (Only the first two letters of the name are significant.) When the name (2 to 5 letters) specified by the CUST command is not already in the custom command table, a new custom command will be entered into the table having an execute address as specified. When the addr is not specified, the beginning address of SOLOS will be used.

When the name specified on the CUST command already exists in the custom command table, this table entry will be replaced with an 'end-of-table' indicator. Therefore, not only will the specified name be removed, but any other custom command names following in the table will also be removed.

Example:    CUST BASIC 0  
                  CUST ALS8 E060

Result:    Two new custom commands are now known.  
                  ALS8 at location E060, and  
                  BASIC at location 0.



### III. TAPE COMMANDS (cont.)

#### Tape Commands in Detail

Get a file from tape                    **GET** (name(/unit) (addr))

This command transfers the specified or next tape file into memory. If a (name/unit) is given, this command will search forward on the cassette until that file is found. The (addr) parameter, if given, specifies the memory location at which the file will be loaded. If the addr is omitted, the file will be loaded as specified in the header.

Example:    GET TARGET/2

Result:    Gets the program "TARGET" from tape unit #2 into memory as specified by the tape file header information. Returns to SOLOS command mode.

Get, then Execute                    **XEQ** (name(/unit) (addr))

This command is an extension of the GET command which gets a tape file and executes as specified by the header information. The (/unit) and (addr) are optional and operate the same as with the GET command.

Example:    XEQ FOCAL

Result:    Gets, then executes, a program named "FOCAL" from tape unit 1.

Save a file                    **SAVE** name (/unit) addr1 addr2 (addr3)

This command transfers program or data onto a tape cassette file name (name) starting at (addr1) and ending at (addr2). The name of the file becomes part of the tape's header information. SET TYPE and SET XEQ commands affect the header information on the tape file. The optional addr3 specifies the address (if different than addr1) to be entered in the tape header.

Example:    SAVE CHASE/2 0 1FF

Result:    Saves onto tape unit 2 a program named "CHASE" starting at location 0000 and ending at location 1FF.

Catalog of files                    **CAT** (/unit)

This command will start the tape unit specified and list each tape file header information.

Example:    CAT /2

Result:    SLOPE 0500 0200  
             HUM 0500 0B00

III. TAPE COMMANDS (cont.)

Note: A very useful feature of the CAT command is to apply power to the tape units when needed to rewind tape. Depressing the MODE (or Control-a) key will remove power from tape unit and return to COMMAND mode.

#### IV. SET COMMANDS

SOLOS has 10 set commands. They are:

<u>SET S</u> =data	Screen character rate
<u>SET I</u> =port	Input port to SOLOS
<u>SET O</u> =port	Output port to SOLOS
<u>SET N</u> =data	Number of NULLS following CRLF
<u>SET XEQ</u> addr	Auto-execute addr.
<u>SET TAPE</u> 0 or 1	0=1200 baud, 1=300 baud
<u>SET TYPE</u> data	Type 'byte' header
<u>SET COUT</u> addr	Custom output addr
<u>SET CIN</u> addr	Custom input addr
<u>SET CRC</u> data	Allows ignoring of tape CRC Read errors

#### Set Commands In Detail

Set Speed of Display                      SET S=0-FF

This command determines character display rate to the screen:

data = 0 - Fastest

data = FF - Slowest

#### Input/Output Command Parameters

The next two SET commands affect SOLOS input and output command parameters.

Set Out Command                              SET O=port

This command selects the output driver routine to which SOLOS routes data. Under SOLOS, COMMAND mode text is always sent to the display screen. Under CUTER, all output goes to the current Output pseudo port. In all cases, the output from each command is sent to the current output pseudo port.

#### IV. SET COMMANDS (cont.)

The Output Pseudo ports command parameter values are:

- Ø = Video Display
- 1 = Serial Output Port
- 2 = Parallel Output Port
- 3 = User Defined by SET COUT command

Example: SET O=1  
DUMP Ø 2F

Result: Select serial output port. 'Dump Ø 2F' would be displayed, but the data would go to the serial output port.

Set In Command                      SET I=port

This command selects the input driver routine to SOLOS. All future input commands would come from the new selected input pseudo port.

The Input Pseudo port parameter values are:

- Ø = Keyboard
- 1 = Serial Input Port
- 2 = Parallel Input Port
- 3 = User defined by SET CIN command

Example: SET I=1

Result: SOLOS would expect the next command to come from the serial port input routine. The Sol keyboard would have no affect except to simultaneously hit repeat and upper case keys to reset the computer.

#### Cassette Tape Parameter Commands

The Following SET commands affect the cassette tape parameters:

Set Tape Command                      SET TAPE Ø or 1

This command selects one of two standard speeds.

- Ø = 12ØØ baud high speed
- 1 = 3ØØ baud low speed

Normally set to Ø.



IV. SET COMMANDS (cont.)

Set Type Command

SET TYPE data

This command sets (data) values into the 'type' byte in the tape header information when used in conjunction with the SAVE command. The 'type' byte data is entered as a hexadecimal value, but it will appear on the screen as an ASCII character when displayed by the GET or CAT command. Only displayable characters should be used for type values (data). The most significant bit of the type value determines if the tape file can be executed automatically by an XEQ command. (0 = Auto-execute, 1 = Not executable.) Typing of tape files can be very useful in grouping common files.

Example: SET TYPE 47

47 = 'G' character for GAME FILES  
Sign Bit = 0, auto-execute

42 = 'B' = BASIC FI  
Sign = 0 = AUTO EXECUTE

SET TYPE 50

50 = 'P' character for PROGRAM FILES  
Sign Bit = 0, auto-execute

52 = 'R' = 011 0111  
Sign = 0 = AUTO EXECUTE

SET TYPE C4

C4 = 'D' character for DATA FILES  
Sign Bit = 1, non-execute

Set Execute Command

SET XEQ addr

This command sets the auto-execute address (addr) word into the tape header information when used in conjunction with the SAVE command. This address word is used by the XEQ command after loading a tape file to begin program execution at location specified by tape header information (addr). Note that the 'TYPE' byte determines if the file is of the auto-execute type.

Example: SET XEQ 200

Result: The auto-execute address of 200 Hex will be written onto the tape header when the next SAVE command is issued.

Custom Input/Output Commands

The next SET commands set address pointers to custom input and output driver routines when 'SET I=3' and/or 'SET O=3' are used. These custom I/O drivers must meet the SOLOS I/O drivers requirements. See the SOLOS software listing for model input routine.

Set Custom Output Command

SET COUT addr

This command informs SOLOS software where the user defined output routine specified by 'addr' is located.

#### IV. SET COMMANDS (cont.)

The Custom Output driver requirements are:

1. The 'addr' (address) word in the SET COUT command will equal the starting address of the output routine.
2. It is the user's responsibility to save registers prior to any modification of the register.
3. The "B" register will contain the data passed from SOLOS for output routine.
4. The output routine will end with a 'RET' instruction or equivalent.

Set Custom Input Command                    SET CIN addr

This command informs SOLOS software where the user defined input routine specified by 'addr' is located.

The Custom Input driver requirements are:

1. The 'addr' address word in the SET CIN command will equal the starting address of the input routine.
2. It is the user's responsibility to save registers prior to any modification of the register.
3. The input routine combines actually inputting the character along with STATUS. The routine returns either a zero flag indicating no character is available or the character in Register "A" with a non-zero flag. The calling program can then take appropriate action based on a zero or non-zero condition.

Set CRC Error Checking                    SET CRC data

This command is used to specify whether or not the standard CRC error checking routines are to be used. When a value of FF is specified, all further tape reads will ignore CRC errors. Any value other than FF indicates standard error checking is to be in effect. This command is very useful to allow a tape to be read in which would otherwise not be readable. When CRC errors are being ignored, it must be remembered that the data read in may not be valid.

Example:    SET CRC FF

Result:    CRC error checking will be set to ignore all CRC errors.

Set Number of NULLS                    SET N=data

This command sets the number of nulls (binary zeroes) to be output following a carriage return-linefeed (CRLF) sequence. The value is

IV. SET COMMANDS (cont.)

initialized to zero but may be set to any number up to FF (hex). This command is useful when using output devices requiring a delay following a carriage return.

Example: SET N=3

Result: Every CRLF issued by SOLOS will be followed by three nulls.

V. SUBROUTINES

A. Introduction to the SOLOS Machine Language Interface

The Machine Language Interface with SOLOS is based on:

1. A predefined set of 'pseudo' I/O ports allowing software compatibility as well as providing an easy means of supporting any I/O device.
2. A system defined register usage when interfacing with SOLOS.
3. A system jump table of entry points.

First are the pseudo ports. Built into SOLOS are four input and four output pseudo ports. I/O requests made to a pseudo port are converted internally to a request either to a specific device, a built-in routine, or a user written routine. All non-tape I/O requests made to SOLOS are made with reference to one of the following pseudo ports.

PSEUDO PORTS FOR SOLOS

<u>Pseudo Port</u>	<u>Input</u>	<u>Output</u>
0	Keyboard	VDM driver
1	Serial port	Serial port
2	Parallel Port	Parallel Port
3	User written routine	User written routine

PSEUDO PORTS FOR CUTER

<u>Pseudo Port</u>	<u>Input</u>	<u>Output</u>
0	Keyboard data from parallel port 3, not KDR status, on port 0, bit 0.	VDM driver
1	Serial port 1, RDA status on port 0, bit 6.	Serial port 1, TBE status on port 0, bit 7.
2	Parallel port 2 with not-PDR status on port 0, bit <del>4</del> 1.	Parallel port 2 with not-PXDR status on port 0, bit 2.
3	User written routine.	User written routine.

V. SUBROUTINES (cont.)

Second are the defined register usages when interfacing at the machine language level with SOLOS.

Whenever a machine program is executed by SOLOS (via the EXEC or XEQ command, or via a custom command), the stack pointer and HL registers are predefined by SOLOS. The stack pointer is set such that the user may perform stacking operations which will use the SOLOS stack. The SOLOS stack begins at the end of the SOLOS RAM area and works its way down from there. Excessive use of this stack can destroy data maintained by SOLOS within its RAM area. The stack is also prepared so that the user may issue a standard RET instruction to return control to SOLOS command mode processor.

\* The HL register pair is initialized to point to the very beginning of SOLOS. It is at this point that the SOLOS jump table begins. The user program may then use the address presented in the HL register pair as the beginning of the jump table.

This address is provided for two reasons:

1. CUTER may be located at any address in memory, providing the means for programs to function with CUTER located at any address, and
2. the first byte of the jump table for SOLOS is different from the first byte for CUTER, providing an easy means of distinguishing between SOLOS and CUTER.

Third is the SOLOS jump table (see next page). All requests to SOLOS should be made based on this jump table and not to the actual routine addresses as scattered throughout SOLOS. By using only this jump table the user can be assured of maintaining compatibility between SOLOS and CUTER. \*\*

Page 15: Paragraph two describing the Stack Pointer and the Stack. Add the following:

\* The Stack itself should be established such that:

- (a) A "Ret" instruction can be used as an exit by the executing program.
- (b) The locations at Stack Pointer -1 and -2 in memory contain the address of the executed program itself. This information can be accessed by machine code similar to:

LXI	H,-1	A constant minus one.
DAD	SP	HL=SP-1 now.
MOV	A,M	A=our own high address.

Code such as this can be used to allow a routine to be made self-relocating to a 256 byte boundary.

Page 15: Paragraph three describing the HL register pair. Add the following:

\*\* The HL register pair is initialized to point to the very beginning of SOLOS. Because the jump table may appear at any 256 byte boundary, register L will be zero.

V. SUBROUTINES (cont.)

JUMP TABLE

<u>Address</u>	<u>Label</u>	<u>Length</u>	<u>Function</u>
C000	START	1	This byte allows power-on reset of SOLOS. It is 00 for SOLOS and 7F for CUTER, providing an easy means of differentiating the exact operating system in use.
C001	INIT	3	This is a "JMP" to the power-on reset.
C004	RETRN	3	Enter at this point to return control to SOLOS command mode processor.
C007	FOPEN	3	Enter here to open a tape file.
C00A	FCLOS	3	Enter here to close a tape file.
C00D	RDBYT	3	Enter here to read a byte from an open tape file.
C010	WRBYT	3	Enter here to write a byte to an open tape file.
C013	RDBLK	3	Enter here to read one tape block into memory based on a header.
C016	WRBLK	3	Enter here to write one tape block from memory based on a header.
C019	SOUT	3	Enter here to output the character in register "B" to the current system output pseudo port. This is always an "LDA" pointing to the byte containing the current system output pseudo port value.
C01C	AOUT	3	Enter here to output the character in register "B" to the pseudo port specified in register "A".
C01F	SINP	3	Enter here to obtain status/character from the current system input pseudo port into register "A". This is always an "LDA" to the byte containing the current system input pseudo port value.
C022	AINP	3	Enter here to obtain status/character from the input pseudo port specified in the "A" register. On return, register "A" will contain the character with the flags set to indicate whether a character is present or not.

## V. SUBROUTINES (cont.)

### B. System Entry Points

There are actually only two system entry points within the SOLOS jump table. Entry at these points does not require that any register be initialized. The first (at either label "START" or "INIT") is used to perform a complete power-on system reset. As a part of the system reset, the system RAM area data used by SOLOS will be cleared. The only reason for entering via "START" or "INIT" is that the power-on circuitry requires a one byte instruction to allow various circuits to stabilize. The other use of the byte labeled "START" is to determine if a user program is being executed under SOLOS or is CUTER controlled. When under SOLOS, this byte will be zero. When under CUTER, this byte will be non-zero.

The other system entry point ("RETRN") is used to return to SOLOS command mode. This entry point does not perform a system reset.

### C. SOLOS Input Entry Points

SINP                    entry point address C01F

This entry point will set register "A" to the current system input pseudo port. The current system input pseudo port is changed by the "SET I=" command. After setting register "A", this command proceeds by executing an "AINP". (See below.)

AINP                    entry point address C022

This entry point is used to input one character or status from any pseudo port. Register "A" on entry indicates the desired input pseudo port from 0 to 3. Because this entry point is a combination status/get-character routine, it is the user's responsibility to interpret return flags properly. When a character is not available, the zero flag will be set and the character will be placed into register "A".<sup>①</sup> What this means is that, if the user wants to wait for a character to be entered, simply follow the CALL AINP (or SINP) with a "JZ" jump-if-zero instruction back to the call. A combined status/get-character routine is very important when allowing user written input routines.

### D. SOLOS Output Entry Points

SOUT                    entry point address C019

This entry point will set register "A" to the current system output pseudo port. The current system output pseudo port is changed by using the "SET O=" command. After setting register "A", this command proceeds by executing an "AOUT". (See next definition.)

<sup>①</sup> When a character is available, the zero flag is reset and the character is in register "A".

V. SUBROUTINES (cont.)

AOUT entry point address C01C

This entry point is used to output one character to any pseudo port. Register "A" is assumed to be a binary value from 0 to 3 indicating the desired output pseudo port. Register "B" will contain the character to be output. On return, the PSW and Register "A" are undefined. All other registers are as they were on entry.

E. SOLOS VDM Display Driver

Because the VDM is much more powerful than a standard hardcopy device, the built-in VDM driver supports many expanded functions. The following characters, when sent to the VDM driver (output pseudo port 0), cause special functions to be performed:

<u>Hex</u>	<u>Character</u>	<u>Function</u>
01	Control-A (SOH)	Move cursor left (wrap mode) one position.
0B	Control-K (VT)	Clear screen; position cursor at home.
0D	Control-M (CR)	Clear remainder of line; then move cursor to beginning of same line.
13	Control-S (DC3)	Move cursor right (wrap mode) one position.
17	Control-W (ETB)	Move cursor up (wrap mode) one line.
1A	Control-Z (SUB)	Move cursor down (wrap mode) one line.

The escape key (hex code 1B) is also a special character to the VDM driver. It initiates what is known as an escape sequence. The escape character is always followed by one or two hexadecimal values (bytes) which indicate what expanded function is to be performed. The following lists the escape sequences and corresponding results. Where a third byte must follow the escape, this will be represented by (##), indicating that this third byte actually contains a value being passed to the VDM driver.

<u>Escape sequence</u>	<u>Function</u>
1B 01 ##	Place the cursor onto position (##) of the current display line. (##) is in the range 00 - 3F.
1B 02 ##	Place the cursor onto line number (##) of the display screen. (##) is in the range 00 - 0F, with the topmost line being line 00.
1B 03	Pass back the current cursor line/character position in Registers BC. Register "B" is set to the character position (00-3F), and Register "C" is set to the line position (00-0F).
1B 04	Pass back the memory address of the current cursor location into Registers "BC".

more escape sequences . . .



V. SUBROUTINES (cont.)

<u>Escape sequence</u>	<u>Function</u>
1B 05 ##	
1B 06 ##	
1B 07 ##	The third byte is output to the VDM at the current cursor position exactly as is, regardless of this byte's value. No check is made of this character (##). Being a control character, it is only placed into the VDM memory as-is, and the cursor is advanced one position.
1B 08 ##	The display speed is set to the value (##) specified. The speed ranges from 00 (fastest) to FF (slowest).
1B 09 ##	This functions the same as escape sequence 01. The cursor is positioned to character position ## of the current display line.

F. Cassette Tape Entry Points to SOLOS

SOLOS contains subroutines to handle data transfer to and from two cassette units. Both block-by-block and byte-by-byte access are available. While performing any tape read, the user can return to the present calling software program by pressing the MODE (or Control-@) key.

In block transfers, each request results in tape movement and a transfer of an information block to or from a location in memory. SOLOS uses block-by-block access to provide the tape commands.

In byte transfers, on the other hand, SOLOS buffers the data into 256 byte blocks, doing cassette operations only once per 256 transfers. BASIC uses byte-by-byte access for data files. Other programs--such as editors, assemblers or special user-written programs--can also call the byte-by-byte routines if a few specific conventions and calling sequences are followed.

File Header

The file header for SOLOS provides specific attributes to a file. These attributes consist of a five ASCII character name and a file type.

File name serves two functions:

1. It permits easy human identification of the file, and
2. It provides the identification for which SOLOS searches to find the correct file.


File type is used in SOLOS to prevent certain operations, such as automatic XEQ, if the file is not of the proper type.

V. SUBROUTINES (cont.)

When calling open the register, pair "HL" should point to a memory location that contains the header. Following is the layout of a SOLOS file header:

NAME	ASC	'12345'	A five character name with trailing binary zeroes
	DB	0	Should always be zero.
TYPE	DB	'B'+80H	File type. If Bit 7=1, then this is a data file (not executable).
SIZE	DW	LENGTH	Length of file in number of bytes.
ADDR	DW	FROM	Address at which file is to be read to or from which it is to be written.
XEQ	DW	EXEC	Auto execute address (ignored for data files).
	DS	3	Space - not currently used by SOLOS.

As previously mentioned, SOLOS uses the name to find the correct data for the file operations. Assume you were about to read data from a file named POTTS, for example, and you had correctly opened the file with a header pointing to that name. SOLOS, when you first requested a data transfer, would read past File 1 and File 2 (as shown below) and then read data from the POTTS file.



Block Access

The Block Access method invokes no management by the system. Each 'call' to the 'Read' or 'Write' routines performs a complete cassette operation. Read and Write routines are used by SOLOS for GET and SAVE commands and serve as examples of the calling conventions for RDBLK and WRBLK routines.

Read Tape Block Routine                      RDBLK

The entry point for RDBLK is C013.

On entry:     Register A contains Unit and Speed data with bit 5 (speed) 0 for 1200 baud (or 1 for 300 baud); bit 7=1 for Tape 1; bit 6=1 for Tape 2; and all other bits=0.

V. SUBROUTINES (cont.)

Registers H & L contain the address of file header information.

Registers D & E contain the address of where the file is to be loaded into memory. (If set to 0, this information is taken from file header information on tape)

On exit: Normal return: Carry Flag is cleared, and data has been transferred into memory.

Error return: On errors, or user pressing MODE (or Control-a) from keyboard, the Carry Flag is set.

Write Tape Block Routine WRBLK

The entry point for WRBLK is C016.

On entry: Register A contains unit and speed with the same bit values as specified for RDBLK.

Registers H & L contain file header address. The file header information will be written onto the specified tape unit followed by the data.

On exit: Normal return: Carry Flag is cleared, and data has been transferred to tape.  
There are no error returns.


Byte Access

Data stored on, or about to be stored on, a tape should be considered a file. In a SOLOS file, data is stored one byte at a time as a string of bytes along the tape with no assumed meaning or structure. It is simply a collection of bytes that can be accessed by someone with responsibility for the intelligence of the data.

When writing to tape, SOLOS records the data in a form that allows the data to be read from the tape later. When reading from tape, SOLOS provides the management to access each byte sequentially.

SOLOS also provides start and stop control of two units. File operations view Unit 1 as File 1 and Unit 2 as File 2. Thus, data in Unit 1 is associated with File 1, and data in Unit 2 is associated with File 2.

When using Byte Access, two important user management operations are necessary. As shown in Figure below, the first is to open a file to tell SOLOS you want to access the file. The second is to close a file to inform SOLOS you are finished with it.



V. SUBROUTINES (cont.)

SOLOS provides entry points to Open, Read, Write and Close tape files. Each of these routines requires that certain conventions be followed to ensure accurate data transfers.

File Open Routine      FOPEN

The Open routine sets up certain internal parameters to keep track of data requests. This operation should be called only once prior to the first access of the file. The File Header information is the same format as in the Block Access mode and is used in both reading and writing of files. If the Byte Accesses are of the Read type, SOLOS will search the tape file until the correct file 'name' is found as specified by the File Header information. On the next Read access, SOLOS will transfer the first data byte of the file. If the Byte Accesses are of the Write type, the File Header information will be transferred onto the file.

The entry point for FOPEN is C007.

On entry:      Register A contains File # (1 or 2) same as tape unit (1 or 2).

Registers H & L contain address of the File Header information.

On exit:      Normal return: All registers are altered and file is ready for accesses.

Error return: The Carry Flag is set. Reason for error: file already open.

Write Byte Routine      WRBYT

The Write Byte routine writes a single byte of data into a buffer file. SOLOS stores this data until it contains 256 bytes. It then writes this block onto the tape, followed by a CRC character (error checking character). SOLOS then resets the buffer file for the next 256 bytes of data.

The entry point for WRBYT is C010.

On entry:      Register A contains File # (1 or 2).

Register B contains the byte of data to be transferred onto tape.

On exit:      Normal return: Carry Flag cleared.

Error return: Carry Flag set - errors caused by:

1. file NOT open, or
2. file previously used for reading.

V. SUBROUTINES (cont.)

Read Byte Routine      RDBYT

The Read Byte routine reads a single byte of data from a buffer file. SOLOS fills this buffer as needed per read request. Each time SOLOS fills the file buffer (reads a block), the CRC character is checked for data accuracy.

The entry point for RDBYT is C00D.

On entry:      Register contains file # (1 or 2)

On exit:      Normal return: Register A contains data byte.  
Carry and Minus Flags set mean 'end of file'.

Error return: Carry Flag set. Errors are caused by:

1. file NOT open
2. file previously used for writing
3. CRC character error
4. pressing MODE (or Control-@) while actually reading from the tape.

Close File Routine      FCLOS

The Close file routine closes the current file and resets the internal parameters for the next open operation. It is very important to close the file after all data transfers are completed. Failure to do so could result in lost data and prevent further open operations.

The entry point for FCLOS is C00A.

On entry:      Register A contains File # (1 or 2) to be closed.

On exit:      Normal return: Carry Flag cleared.

Error return: Carry Flag set. (Error is caused by file NOT open.)

VI. LOADING & EXECUTING CUTER (Applicable to CUTER only)

CUTER is available (1) on cassette tape with its own loader which can be loaded at any memory address from 0200 through F400, or (2) in ROM at the address C000. In order to load CUTER from cassette tape, perform the following steps. When CUTER is being used in ROM, the procedure is much simpler: make sure the sense switches are set according to H below prior to executing location C000.

A. Verify that the hardware is connected and functioning properly.

B. Enter the following bootstrap routine into memory beginning at location 0. The following is presented in a format similar to that produced by a "DUMP" command with an address shown every 10 (hex) bytes:

```
0000: 21 40 00 F9 45 4D 3E 80 D3 FA E7 05 C2 0A 00 E7
0010: 3D C2 0F 00 E7 02 03 FE DD C2 14 00 E9 00 00 00
0020: DB FA A5 CA 20 00 DB FB C9
```

C. Verify that the above bootstrap is in memory exactly as presented.

D. Set the sense switches to the address at which CUTER is to be loaded. The sense switches will be the hi-order byte of the memory address, with the lo-order byte zero. As an example: Sense switches set to 34 hex will cause CUTER to be loaded into memory beginning at location 3400 hex. For convenience, a memory address should be selected that also specifies the default I/O pseudo ports (see "H" below). The address specified must be between 0200 and F400. Remember, however, that CUTER occupies 2K of memory and uses 1K of RAM beyond that.

E. Make sure that the CUTER tape is rewound and placed into the proper cassette machine. The CUTER bootstrap will activate the motor control for tape unit one. If your cassette machine motor control is attached as tape unit one, you may now place the machine into "PLAY" mode.

F. Execute location zero (the bootstrap). This can be accomplished by allowing a "Reset" to specify an address of zero. At this time, be certain that the cassette machine is in "PLAY" mode and is activated.

G. When completed, the CUTER loader program will "HALT". This is not an error condition. When completed, the motor control will also be turned off.

VI. LOADING & EXECUTING CUTER (cont.) (Applicable to CUTER only)

H. Via sense switches, select the default I/O pseudo ports as follows:

	X X X X	I I O O
Bit	7 6 5 4	3 2 1 0

Where: X X X X doesn't matter

I I which pseudo port from 0 - 3 (00-11 binary)  
is to be the default input pseudo port.

O O which pseudo port from 0 - 3 (00-11 binary)  
is to be the default Output pseudo port.

NOTE: Whenever CUTER does a full system reset (begins execution at its beginning memory address), the sense switches will be accessed to determine the default I/O pseudo ports.

I. If either Input or Output default is to be pseudo port 3 (user written routine), verify the following:

(i) The appropriate user written routine is in memory.

(ii) The address of the appropriate I/O routine is entered into the CUTER system RAM area. The system RAM area begins exactly 2K (800 hex) after the beginning of CUTER. The first word of this area is used to contain the address for the user Input routine. The second word will contain the address of the user Output routine. Addresses are entered in lo-hi order.

J. Execute location ZERO. The CUTER loader will have properly prepared this location to either transfer control to the CUTER just loaded or to indicate an error while loading CUTER. If there was no error, CUTER will now be in control.

Remember to turn off the cassette machine and remove the CUTER tape.

K. IF your computer halts again, this means one of the following errors has occurred. Display memory location ONE to determine the error code. The error code will be one of the following:

<u>Error Code in Hex</u>	<u>Meaning</u>
00	The specified load address was not within the range 0200-F400, or the tape file loaded was not CUTER.
01	A tape read error was detected.
02	There was no tape read error, but the CRC (error checking) character was invalid.
40	The file was loaded, but it was not CUTER.

MANUAL DATA  
CUTS READ AND WRITE ROUTINES

\*\* ALS-8 PROGRAM DEVELOPMENT SYSTEM \*\*

PROCESSOR TECHNOLOGY CORP.  
6200 HOLLIS STREET  
EMERYVILLE, CALIF. 94608

```
0001 *
0002 *
0003 *
0004 *      TAPE READ AND WRITE ROUTINES FOR CUTS BOARDS
0005 *
0006 *
0007 *      THESE ROUTINES WERE EXTRACTED FROM "SOLOS" AND "CUTER"
0008 *      TO ILLUSTRATE THE REQUIREMENTS OF THE CUTS BOARD FOR
0009 *      READING AND WRITING TO THE CASSETTE TAPE. BOTH SOLOS AND
0010 *      CUTER ALSO HAVE FILE BUFFERING ROUTINES TO PROVIDE BYTE
0011 *      BY BYTE TRANSFERS TO THE CASSETTE TAPE.
0012 *
0013 *      CUTER resides on cassette tape and is available at your
0014 *      local Processor Technology Dealer for $11.00 or ROM
0015 *      resident for use on the GPM module. The CUTER program
0016 *      requires 2K of memory plus 1k of RAM work area. A short
0017 *      bootstrap program is used to load CUTER from cassette
0018 *      tape.
0019 *
0020 *      CUTER is relocatable to any 256 byte boundary and has a
0021 *      built in command processor and support for serial,
0022 *      parallel, keyboard and VDM I/O as well as CUTS cassette
0023 *      routines. The CUTER software is necessary for all major
0024 *      Processor Technology or Software Technology programs.
0025 *
0026 *      CUTER COMMAND LIST
0027 *
0028 *      DUMP      Dump memory
0029 *      ENTER     Enter to memory
0030 *      EXECUTE   Execute a program
0031 *      TLOAD    Load programs or data from cassette
0032 *      TSAVE    Save programs or data to cassette
0033 *      TXEQ     Load and run program from tape
0034 *      TCAT     List names of files on tape
0035 *      CUST     Enter or delete custom command name
0036 *      SET di   Set display speed
0037 *      SET nu   Set output nulls
0038 *      SET ta   Set tape speed
0039 *      SET in   Set input port (0-3)
0040 *      SET out  Set output port (0-3)
0041 *      SET cin  Set custom input driver address
0042 *      SET cout Set custom output driver address
0043 *      SET xeq  Set auto execute address to header
0044 *      SET type Set type in header
0045 *
0046 *
0047 *
0048 *
0049 *
0050 *
0051 *      <<-- TAPE READ ROUTINES -->
```



\*\* ALS-8 PROGRAM DEVELOPMENT SYSTEM \*\*

MANUAL DATA  
CUTS READ AND WRITE ROUTINES

PROCESSOR TECHNOLOGY CORP.  
6200 HOLLIS STREET  
EMERYVILLE, CALIF. 94608

```

0052 *
0053 *
0054 *   ON ENTRY:   A  - HAS UNIT AND SPEED
0055 *             HL - POINT TO HEADER BLOCK
0056 *             DE - HAVE OPTIONAL PUT ADDRESS
0057 *
0058 *   ON EXIT:   CARRY IS SET IF ERROR OCCURRED
0059 *             DE HAVE SIZE OF BLOCK READ
0060 *             TAPE UNITS ARE OFF
0061 *
0062 *
0063 RTAPE  PUSH  D          SAVE OPTIONAL ADDRESS
0064       MVI  B,3          SHORT DELAY
0065       CALL TON
0066       IN   TDATA        CLEAR THE UART FLAGS
0067 *   LOOP HERE UNTIL VALID HEADER IS FOUND
0068 PTAP1  PUSH  H          HEADER ADDRESS
0069       CALL RHEAD        GO READ HEADER
0070       POP  H
0071       JC   TERR          IF AN ERROR OR ESC WAS RECEIVED
0072       JNZ  PTAP1        IF VALID HEADER NOT FOUND
0073 *   FOUND A VALID HEADER NOW DO COMPARE
0074       PUSH H             GET BACK AND RESAVE ADDRESS
0075       LXI D,THEAD
0076       CALL DHCMP        COMPARE DE-HL HEADERS
0077       POP  H
0078       JNZ  PTAP1        DIDN T COMPARE...GO BACK TO LOOP
0079 *   FOUND IT.. NOW ADJUST REGISTERS FOR READ
0080       POP  D             OPTIONAL "PUT" ADDRESS
0081       MOV  A,D
0082       ORA  E             SEE IF DE IS ZERO
0083       LHLD BLOCK        GET BLOCK SIZE
0084       XCHG .             ..TO DE
0085 *   DE HAS HBLOCK...HL HAS USER OPTION
0086       JNZ  RTAP         IF DE WAS ZERO GET TAPE LOAD ADDRESS
0087       LHLD LOADR        GET TAPE LOAD ADDRESS
0088 *
0089 *
0090 *   THIS ROUTINE READS "DE" BYTES FROM THE TAPE
0091 *   TO ADDRESS HL. THE BYTES MUST BE FROM ONE
0092 *   CONTIGUOUS PHYSICAL BLOCK ON THE TAPE.
0093 *
0094 *   HL HAS "PUT" ADDRESS
0095 *   DE HAS SIZE OF TAPE BLOCK
0096 *
0097 RTAP   PUSH  D          SAVE SIZE FOR RETURN TO CALLING PROGRAM
0098 *
0099 LOLOOP MOV  A,D          GET COUNT
0100       ORA  E
0101       JZ   RTOFF        COUNT IS ZERO-TURN OFF TAPE AND RETURN
0102       XCHG              GET COUNT TO HL
0103 *
0104       LXI  B,-256        THIS MANY PRIOR TO CRC TEST

```

\*\* ALS-8 PROGRAM DEVELOPMENT SYSTEM \*\*

MANUAL DATA  
CUTS READ AND WRITE ROUTINES

PROCESSOR TECHNOLOGY CORP.  
6200 HOLLIS STREET  
EMERYVILLE, CALIF. 94608

0035 09	0105	DAD	B	A LITTLE MATH
0036 D2 4E 00	0106	JNC	LBLK	NO CARRY IT S THE LAST BLOCK
0039 06 00	0107	MVI	B,0	256 TO READ
003B D3 FC	0108	OUT	0FCH	DING THE PORT FOR INSECURE ROBERTS
	0109 *			
003D 0E 00	0110 RDBLK	MVI	C,0	ZERO THE CRC
003F EB	0111 *	XCHG	.	ROUND ROBIN
	0112 *			
0040 CD 7D 00	0113 RTLOP	CALL	RHED1	READ IN THIS BLOCK
0043 DA 49 00	0114	JC	TERR	IF ERROR OR ESC
0046 CA 2C 00	0115	JZ	LOLOOP	CONTINUE LOOP IF CRC TEST IS OK
	0116 *			
	0117 *	ERROR RETURN		
	0118 *			
0049 AF	0119 TERR	XRA	A	
004A 37	0120	STC	.	SET ERROR FLAGS
004B C3 5B 00	0121	JMP	RTOF1	
	0122 *			
	0123 *	LAST BLOCK--PUT FINAL COUNT IN B		
	0124 *			
004E 45	0125 LBLK	MOV	B,L	GET LOWER PORTION OF COUNT
004F 21 00 00	0126	LXI	H,0	TELL DE WE ARE FINISHED
0052 C3 3D. 00	0127	JMP	RDBLK	
	0128 *			
	0129 *			
0055 06 01	0130 TOFF	MVI	B,1	SHORT DELAY AFTER WRITE
0057 CD 1F 01	0131 *	CALL	DELAY	
	0132 *			
005A AF	0133 RTOFF	XRA	A	
005B D3 FA	0134 RTOF1	OUT	STAPT	TURN OFF THE TAPE
005D D1	0135	POP	D	RETURN BYTE COUNT
005E C9	0136	RET		
	0137 *			
	0138 *			
	0139 *			
	0140 *	READ THE HEADER		
	0141 *			
005F 06 0A	0142 RHEAD	MVI	B,10	FIND 10 NULLS
0061 CD 8F 00	0143 RHEAL	CALL	STAT	
0064 D8	0144	RC		IF ESCAPE
0065 DB FB	0145	IN	TDATA	IGNORE ERROR CONDITIONS
0067 B7	0146	ORA	A	ZERO?
0068 C2 5F 00	0147	JNZ	RHEAD	
006B 05	0148	DCR	B	
006C C2 61 00	0149	JNZ	RHEAL	LOOP UNTIL 10 IN A ROW
	0150 *			
	0151 *	WAIT FOR THE START CHARACTER		
	0152 *			
006F CD 9D 00	0153 SOHL	CALL	TAPIN	
0072 D8	0154	RC	.	ERROR OR ESCAPE
0073 3D	0155	DCR	A	
0074 C2 6F 00	0156	JNZ	SOHL	WAIT FOR A '1
	0157 *			

\*\* ALS-8 PROGRAM DEVELOPMENT SYSTEM \*\*

PROCESSOR TECHNOLOGY CORP.  
6200 HOLLIS STREET  
EMERYVILLE, CALIF. 94608

MANUAL DATA  
CUTS READ AND WRITE ROUTINES

```

0158 *
0159 *      NOW GET THE HEADER
0160 *
0077 21 2D 01      0161      LXI      H,THEAD      POINT TO BUFFER
007A 01 00 10      0162      LXI      B,HLEN*256  LENGTH OF HEADER IN B ,C<0
                                0163 *
007D CD 9D 00      0164 RHED1   CALL      TAPIN      GET BYTE
0080 D8              0165      RC
0081 77              0166      MOV      M,A          STORE IT
0082 23              0167      INX      H          INCREMENT ADDRESS
0083 CD E6 00       0168      CALL      UDCRC     NOW CALCULATE THE CRC
0086 05              0169      DCR      B          WHOLE HEADER YET?
0087 C2 7D 00       0170      JNZ      RHED1     LOOP UNTIL DONE
0171 *
0172 *      THIS ROUTINE GETS THE NEXT BYTE AND COMPARES IT
0173 *      TO THE VALUE IN REGISTER C.  THE FLAGS ARE SET ON
0174 *      RETURN.
0175 *
008A CD 9D 00       0176 CRCK    CALL      TAPIN      GET CRC BYTE
008D A9              0177      XRA      C          COMPARE IT WITH CALCULATED (CLEAR CARRY)
008E C9              0178      RET
0179 *
0180 *
0181 *      THIS ROUTINE GETS THE NEXT AVAILABLE BYTE FROM THE
0182 *      TAPE.  WHILE WAITING FOR THE BYTE THE KEYBOARD IS TESTED
0183 *      FOR AN ESC COMMAND.  IF RECEIVED THE TAPE LOAD IS
0184 *      TERMINATED AND A RETURN TO THE COMMAND MODE IS MADE
0185 *
008F DB FA          0186 STAT    IN        STAPT
0091 E6 40          0187      ANI      TDR
0093 C0              0188      RNZ      .          WHEN CHARACTER IS READY
0094 DB 01          0189      IN        KDATA
0096 FE 1B          0190      CPI      MODE      ESC ?
0098 C2 8F 00       0191      JNZ      STAT
009B 37              0192      STC      .          SET ERROR FLAG
009C C9              0193      RET        AND RETURN
0194 *
0195 *
0196 *
009D CD 8F 00       0197 TAPIN   CALL      STAT      WAIT UNTIL A CHARACTER IS AVAILABLE
00A0 D8              0198      RC
0199 *
00A1 DB FA          0200 TREDY   IN        STAPT
00A3 E6 18          0201      ANI      TFE+TOE    DATA ERROR?
00A5 DB FB          0202      IN        TDATA      GET THE DATA
00A7 C8              0203      RZ        .          IF NO ERRORS
00A8 37              0204      STC      .          SET ERROR FLAG
00A9 C9              0205      RET
0206 *
0207 *
0208 *
0209 *
0210 *      WRITE TAPE BLOCK ROUTINE

```

\*\* ALS-8 PROGRAM DEVELOPMENT SYSTEM \*\*

MANUAL DATA  
CUTS READ AND WRITE ROUTINES

PROCESSOR TECHNOLOGY CORP  
6200 HOLLIS STREET  
EMERYVILLE CALIF. 94608

```

0211 *
0212 *   ON ENTRY:  A - HAS UNIT AND SPEED
0213 *             HL - HAVE POINTER TO HEADER
0214 *
0215 *
00AA E5      0216 WTAPE  PUSH   H           SAVE HEADER ADDRESS
00AB CD ED 00 0217      CALL   WHEAD        WRITE THE HEADER
00AE L1      0218      POP    H
00AF 11 07 00 0219      LXI   D BLKOF      OFFSET TO BLOCK SIZE IN HEADER
00B2 19      0220      DAD    D           HL POINT TO BLOCK SIZE
0221 *   GET ADDRESS AND SIZE FROM HEADER
00B3 5E      0222      MOV    E,H
00B4 23      0223      INX    H
00B5 56      0224      MOV    D,M        DE HAVE SIZE
00B6 23      0225      INX    H           POINT TO STARTING ADDRESS
00B7 7E      0226      MOV    A,M
00B8 23      0227      INX    H
00B9 66      0228      MOV    H,M
00BA 6F      0229      MOV    L,A
00BB E5      0230 WRLOL  PUSH   H           HL HAVE STARTING ADDRESS
                                         FOR STACK CLEAN UP ON TURN OFF
0231 *
0232 *
0233 *   THIS ROUTINE WRITES ONE PHYSICAL BLOCK ON THE
0234 *   TAPE "DE" BYTES LONG FROM ADDRESS "HL .
0235 *
00BC 7A      0236 WRLOP  MOV    A,D
00BD B3      0237      ORA    E           TEST IF COUNT IS ZERO
00BE CA 55 00 0238      JZ     TOFF
00C1 01 00 FF 0239      LXI   B,-256      SUBTRACT 256 FROM IT
00C4 EB      0240      XCHG
00C5 09      0241      DAD    B
00C6 D2 D4 00 0242      JNC   WLBLK      IF 256 WEREN T LEFT
00C9 06 00    0243      MVI   B,0
0244 *
00CB 0E 00    0245 WDBLK  MVI   C,0        CRC STARTS WITH ZERO
00CD EB      0246      XCHG
00CE CD 02 01 0247 WDBL1  CALL  WLOOP      RESTORE COUNT TO DE., ADDRESS TO HL
00D1 C3 BC 00 0248      JMP   WRLOP      WRITE OUT THE BLOCK
                                         AND GO BACK TO MAJOR LOOP
0249 *
00D4 45      0250 WLBLK  MOV    B,L        REMAINDER OF COUNT
00D5 21 00 00 0251      LXI   H,0
00D8 C3 CB 00 0252      JMP   WDBLK      TELL DE WE ARE DONE
0253 *
00DB F5      0254 WRBYT  PUSH  PSW        SAVE CHARACTER
00DC DB FA    0255 WRWAT  IN    0FAH      GET UART STATUS
00DE E6 80    0256      ANI   80H
00E0 CA DC 00 0257      JZ     WRWAT      WAIT UNTIL IT IS READY
00E3 F1      0258      POP   PSW
00E4 D3 FB    0259      OUT  0FBH      OUTPUT THE CHARACTER
0260 *
0261 *   THIS ROUTINE UPDATES THE CRC
0262 *
00E6 91      0263 UDRC   SUB    C           FORM PARTIAL

```

\*\* ALS-8 PROGRAM DEVELOPMENT SYSTEM \*\*

PROCESSOR TECHNOLOGY CORP  
6200 HOLLIS STREET  
EMERYVILLE CALIF 94608

MANUAL DATA  
CUTS READ AND WRITE ROUTINES

00E7 4F	0264	MOV	C,A	SAVE IT	
00E8 A9	0265	XRA	C	NOW BEND IT OUT	
00E9 2F	0266	CMA	.	GET A FF	
00EA 91	0267	SUB	C	CRC+1-1 IS NOT THE SAME	
00EB 4F	0268	MOV	C,A	AND RESAVE IT	
00EC C9	0269	RET			
	0270 *				
	0271 *				
	0272 *	THIS ROUTINE WRITES THE HEADER POINTED TO BY			
	0273 *	HL TO THE TAPE.			
	0274 *				
00ED CD 1B 01	0275	WHEAD	CALL	WTON	TURN ON THE TAPE AND DELAY
00F0 16 32	0276		MVI	D,50	WRITE 50 ZEROS
00F2 AF	0277	NULOP	XRA	A	
00F3 CD DB 00	0278		CALL	WRBYT	
00F6 15	0279		DCR	D	
00F7 C2 F2 00	0280		JNZ	NULOP	
	0281 *				
00FA 3E 01	0282		MVI	A,1	50 ZEROS FOLLOWED BY A ONE
00FC CD DB 00	0283		CALL	WRBYT	
00FF 01 00 10	0284		LXI	B,HLEN*256	HEADER LENGTH TO B, ZERO TO C
	0285 *				
0102 7E	0286	WLOOP	MOV	A,M	GET CHARACTER
0103 CD DB 00	0287		CALL	WRBYT	WRITE IT TO THE TAPE
0106 05	0288		DCR	B	
0107 23	0289		INX	H	
0108 C2 02 01	0290		JNZ	WLOOP	
010B 79	0291		MOV	A,C	GET CRC
010C C3 DB 00	0292		JMP	WRBYT	PUT IT ON THE TAPE AND RETURN
	0293 *				
	0294 *				
	0295 *	THIS ROUTINE COMPARES THE HEADER IN THEAD TO			
	0296 *	THE USER SUPPLIED HEADER ADDRESS IN HL.			
	0297 *	ON RETURN IF ZERO IS SET IF THE TWO NAMES COMPARED			
	0298 *				
010F 06 05	0299	DHCMP	MVI	B,5	COMPARE FIVE CHARACTERS
0111 1A	0300	DHLOP	LDAX	D	GET ONE PART
0112 8E	0301		CMP	M	COMPARE IT WITH THE OTHER
0113 C0	0302		RNZ	.	RETURN IF NOT THE SAME
0114 05	0303		DCR	B	
0115 C8	0304		RZ	.	IF ALL FIVE COMPARED
0116 23	0305		INX	H	COMPARE THE NEXT
0117 13	0306		INX	D	
0118 C3 11 01	0307		JMP	DHLOP	
	0308 *				
	0309 *				
011B 06 04	0310	WTON	MVI	B,4	SET LOOP DELAY
011D D3 FA	0311	TON	OUT	STAPT	TURN ON THE SELECTED DRIVE
	0312 *				
011F 11 00 00	0313	DELAY	LXI	D,0	
0122 1B	0314	DLOP1	DCX	D	
0123 7A	0315		MOV	A,D	
0124 B3	0316		ORA	E	

\*\* ALS-8 PROGRAM DEVELOPMENT SYSTEM \*\*

MANUAL DATA  
CUTS READ AND WRITE ROUTINES

PROCESSOR TECHNOLOGY CORP  
6200 HOLLIS STREET  
EMERYVILLE, CALIF. 94608

0125 C2 22 01	0317	JNZ	DLOP1	LOOP HERE UNTIL DE ARE ZERO
0128 05	0318	DCR	B	
0129 C2 1F 01	0319	JNZ	DELAY	LOOP HERE UNTIL B IS ZERO
012C C9	0320	RET		

0321 \*  
0322 \*  
0323 \*  
0324 \*  
0325 \*  
0326 \*  
0327 \*  
0328 \*

PORT ASSIGNMENTS

00 FA	0329 STAPT	EQU	0FAH	STATUS PORT GENERAL
00 FB	0330 TDATA	EQU	0FBH	TAPE DATA
00 01	0331 KDATA	EQU	1	KEYBOARD DATA PORT FOR ESCAPE TEST
00 1B	0332 MODE	EQU	1BH	ESCAPE KEY

0333 \*  
0334 \*  
0335 \*  
0336 \*  
0337 \*  
0338 \*

BIT ASSIGNMENT MASKS

00 08	0339 TFE	EQU	8	TAPE FRAMING ERROR
00 10	0340 TOE	EQU	16	TAPE OVERFLOW ERROR
00 40	0341 TDR	EQU	64	TAPE DATA READY
00 80	0342 TTBE	EQU	128	TAPE TRANSMITTER BUFFER EMPTY
	0343 *			
00 40	0344 TAPE1	EQU	64	TAPE ONE OFF BIT
00 80	0345 TAPE2	EQU	128	TAPE TWO OFF BIT

0346 \*  
0347 \*  
0348 \*

GLOBAL AREA

0349 \*  
0350 \*

SYSTEM PARAMETER AREA

012D	0351 *			
0132	0352 *			
0133	0353 *			
0134	0354 *			
0136	0355 *			
0138	0356 *			
013A	0357 *			
	0358 THEAD	DS	5	NAME
	0359	DS	1	THIS BYTE MUST BE ZERO FOR AUTO EXECUTE
	0360 HTYPE	DS	1	TYPE
	0361 BLOCK	DS	2	BLOCK SIZE
	0362 LOADR	DS	2	LOAD ADDRESS
	0363 XEQAD	DS	2	AUTO EXECUTE ADDRESS
	0364 HSPR	DS	3	SPARES
	0365 *			
00 10	0366 HLEN	EQU	5	THEAD LENGTH OF HEADER
00 07	0367 BLKOF	EQU		BLOCK-THEAD OFFSET TO BLOCK SIZE
	0368 *			
	0369 *			

\*\* . ALS-8 PROGRAM DEVELOPMENT SYSTEM \*\*

MANUAL DATA  
CUTS READ AND WRITE ROUTINES

PROCESSOR TECHNOLOGY CORP.  
6200 HOLLIS STREET  
EMERYVILLE, CALIF. 94608

0370 \*

BLKOF	0007	0219			
BLOCK	0134	0083	0367		
CRCK	008A				
DELAY	011F	0131	0319		
DHCOMP	010F	0076			
DHLOP	0111	0307			
DLOP1	0122	0317			
HLEN	0010	0162	0284		
HSPR	013A				
HTYPE	0133				
KDATA	0001	0189			
LBLK	004E	0106			
LOADR	0136	0087			
LOLOO	002C	0115			
MODE	001B	0190			
NULOP	00F2	0280			
PTAP1	0008	0072	0078		
RDBLK	003D	0127			
RHEAL	0061	0149			
RHEAD	005F	0069	0147		
RHED1	007D	0113	0170		
RTAP	002B	0086			
RTAPE	0000				
RTLOP	0040				
RTOP1	005B	0121			
RTOFF	005A	0101			
SOHL	006F	0156			
STAPT	00FA	0134	0186	0200	0311
STAT	008F	0143	0191	0197	
TAPE1	0040				
TAPE2	0080				
TAPIN	009D	0153	0164	0176	
TDATA	00FB	0066	0145	0202	
TDR	0040	0187			
TERR	0049	0071	0114		
TFE	0008	0201			
THEAD	012D	0075	0161	0366	0367
TOE	0010	0201			
TOFF	0055	0238			
TON	011D	0065			
TREDY	00A1				
TTBE	0080				
UDCRC	00E6	0168			
WDBL1	00CE				
WDBLK	00CB	0252			
WHEAD	00ED	0217			
WBLK	00D4	0242			
WLOOP	0102	0247	0290		
WRBYT	00DB	0278	0283	0287	0292
WRL01	00BB				
WRLOP	00BC	0248			

\*\* ALS-8 PROGRAM DEVELOPMENT SYSTEM \*\*

MANUAL DATA  
CUTS READ AND WRITE ROUTINES

PROCESSOR TECHNOLOGY CORP.  
6200 HOLLIS STREET  
EMERYVILLE CALIF. 94608

WRWAT 00DC 0257  
WTAPE 00AA  
WTUN 011B 0275  
XEQAD 0138



PORT  $\phi$  ASSIGNMENTS - INPUT

PRESENT		FOR PORT #:		I/O	PROPOSED	
BIT						
0	SELECTRIC CASE	3		NEW <sub>2</sub> OUT	0	$\overline{KDR}$ PORT 3 Keyboard in
1	- UNASSIGNED -				1	$\overline{PDR}$ PORT 2
2	TAPE READER (XDA)	2		IN	2	$\overline{PXDR}$ PORT 2
3	- UNASSIGNED -				3	UNASSIGNED
4	TAPE PUNCH (XDRA)	2			4	<del>UNASSIGNED</del> SELECTRIC CASE - Port
5	SELECTRIC (XDRB)	3		OUT OK	5	XDRB Port 3 (detectic ready)
6	TVT (RDA)	1		OK	6	RDA Port 1 } TVT, NO CHANGE
7	TVT (TBE)	1		OK	7	TBE Port 1 }

CHANGES

1. Move selectric case bit from bit 0 to bit 4  
 Modify selectric I/O routine (paper type) to accommodate bit 4
2. Move PTR ready from bit 2 to bit 1 ( $\phi 4$  to  $\phi 2$ )  
 Modify Intel monitor in PROM to accommodate
3. Move PTP ready from bit 4 to bit 2 ( $1\phi$  to  $\phi 4$ )  
 Modify Intel monitor in PROM to accommodate
- 4.

