


DeckLink Multibrige™ all in one analog converter and breakout box



Welcome to Multibrige

Instructions

To change your DeckLink Multibrige settings, first you need to install the DeckLink Multibrige Utility software available on the CD included with your DeckLink Multibrige or from the Blackmagic Design web site support page. Check <http://www.blackmagic-design.com>


Installing DeckLink Multibrige Utility Software

The DeckLink Multibrige Installer package will load a USB 2.0 driver onto your system and add the DeckLink Multibrige Utility application into your applications or programs folder. To use the application you must connect a DeckLink Multibrige to your USB port.


Running DeckLink Multibrige Utility

- 1) Connect the DeckLink Multibrige power supply.
- 2) Connect the USB cable. Most USB ports are now USB 2.0, however, the DeckLink Multibrige Utility software will run with USB 1.0 ports.
- 3) Open the DeckLink Multibrige Utility application. The settings should be adjustable. If they are "grayed out" it indicates your computer is not communicating with your DeckLink Multibrige. In this case, check the USB connection or try another USB port on your computer.
- 4) The firmware running on your DeckLink Multibrige may be out of date. If the DeckLink Multibrige Utility detects an older version you will see a message asking you to update the firmware. You must allow the firmware to be updated before you can use this newer version of DeckLink Multibrige Utility to configure your DeckLink Multibrige.
- 5) If the firmware has been updated it is important that you unplug both the USB and power cables from your DeckLink Multibrige, wait 5 seconds and then plug in the power, and then the USB cables in that order. This ensures DeckLink Multibrige is reset correctly.
- 6) The DeckLink Multibrige Utility represents the settings of your DeckLink Multibrige by displaying an interactive rear view picture of the DeckLink Multibrige itself. Each connection is set via a drop-down menu. Select the input or output source from a connections drop-down menu to set the source, destination, format type, or audio embedding channels. If you don't know which drop-down menu to use simply look at the DeckLink Multibrige itself, find the connector you are interested in and then use the correct drop-down menu to change settings for this connector.


Rear view DeckLink Multibrige SD™ 4:2:2 Model



Front view DeckLink Multibrige™ All Models



Workflow diagram DeckLink Multibrige™



Digital Audio connection AES/EBU 8 Channels IN and 8 Channels OUT

DB-25 pin outs also compatible with Yamaha™, Mackie™, Sony™ and Apogee™ connectors

Audio Channels	Hot Pins (+)	Cold Pins (-)	Ground Pins
1&2 IN	1	14	10
3&4 IN	2	15	12
5&6 IN	3	16	13
7&8 IN	4	17	22
1&2 OUT	5	18	23
3&4 OUT	6	19	24
5&6 OUT	7	20	25
7&8 OUT	8	21	

