




Jumpers/Switches/Controls




= jumpered

 = unjumpered


 = 1-2 jumpered

 = 2-3 jumpered

JM3  (default) On-board video does not drive IRQ9.


 On-board VGA drives IRQ9.

JM4  Monochrome adapter installed.

 (default) Color adapter installed.

JM5  00000011.gif On-board VGA disabled.


 (default) On-board VGA enabled.

JM6  (default) Normal.


 IDE pin 21/IOCHRDY.

 IDE pin 27/IOCHRDY.


JM7  Hard-disk IDE interface disabled.

 (default) Hard-disk IDE interface enabled.


JM8  (default) IDE drives that tristate IRQ14.

 IDE drives that do not tristate IRQ14.

JM9

00000024.gif

Disable on-board diskette controller.

 (default)

Enable on-board diskette controller.



For comments and suggestions about the Dell Service and Support Center.

Copyright 1997 Dell Computer Corporation. All rights reserved.
(Terms of Use)