

## **DIAGNOSTIC MAPs**

**Place the hard-tab page labeled "DIAGNOSTIC MAPs" in place of this page, then discard this page.**



# DIAGNOSTIC MAPs

MAP 0020: Power Start .....	0020-1
MAP 0020: Power (PC) .....	0020-1
MAP 0020: Power (AT) .....	0020-1
MAP 0100: System Board Start .....	0100-1
MAP 0100: System Board (PC) .....	0100-1
MAP 0100: System Board (AT) .....	0100-1
MAP 0200: Memory Start .....	0200-1
MAP 0200: Memory (PC) .....	0200-1
MAP 0200: Memory (XT) .....	0200-1
MAP 0200: PC Family Expansion Memory .....	0200-1
MAP 0200: Memory (AT) .....	0200-1
MAP 0300: Keyboard Start .....	0300-1
MAP 0300: Keyboard (PC) .....	0300-1
MAP 0300: Keyboard (AT) .....	0300-1
MAP 0400: Monochrome Display and Printer Adapter .....	0400-1
MAP 0500: Color/Graphics Monitor Adapter ..	0500-1
MAP 0600: Diskette Drive Start .....	0600-1
MAP 0600: Full-High Diskette Drive .....	0600-1
MAP 0600: Diskette Drive (Portable PC) .....	0600-1
MAP 0600: Diskette Drive (AT) .....	0600-1
MAP 0700: Math Coprocessor .....	0700-1
MAP 0900: Parallel Port Start .....	0900-1
MAP 0900: Printer Adapter .....	0900-1
MAP 0900: Serial/Parallel Adapter - Parallel Port .....	0900-1
MAP 1000: Alternate Serial/Parallel Adapter - Parallel Port .....	1000-1
MAP 1100: Serial Port Start .....	1100-1
MAP 1100: Asynchronous Communications Adapter .....	1100-1
MAP 1100: Serial/Parallel Adapter - Serial Port	1100-1
MAP 1200: Alternate Serial Port Start .....	1200-1
MAP 1200: Alternate Asynchronous Communications Adapter .....	1200-1
MAP 1200: Alternate Serial/Parallel Adapter - Serial Port .....	1200-1
MAP 1300: Game Control Adapter .....	1300-1

MAP 1400: Graphics Printer .....	1400-1
MAP 1500: Synchronous Data Link Control (SDLC) Communications Adapter .....	1500-1
MAP 1700: Fixed Disk Drive Start .....	1700-1
MAP 1700: Fixed Disk Drive (PC) .....	1700-1
MAP 1700: Fixed Disk Drive (AT) .....	1700-1
MAP 1800: Expansion Unit .....	1800-1
MAP 2000: Binary Synchronous Communications (BSC) Adapter .....	2000-1
MAP 2100: Alternate Binary Synchronous Communications (Alt BSC) Adapter .....	2100-1
MAP 2200: Cluster Adapter .....	2200-1
MAP 2400: Enhanced Graphics Adapter .....	2400-1
MAP 2900: Color Printer .....	2900-1
MAP 3000: PC Network Adapter .....	3000-1
MAP 3100: Alternate PC Network Adapter ...	3100-1
MAP 3300: Compact Printer .....	3300-1
MAP 3600: IBM General Purpose Interface Bus (GPIO) Adapter .....	3600-1
MAP 3800: IBM Data Acquisition and Control Adapter .....	3800-1
MAP 3900: IBM Professional Graphics Controller .....	3900-1
MAP 7100: Voice Communications Adapter ...	7100-1
<b>Supplemental MAPS:</b>	

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---