

Procedure for update

Update using Panasonic camera body

Please make sure that your camera body firmware is updated to the latest version first, when updating the lens firmware.

Firmware Update Workflow

Step 1. Preparation of update program

- 1-1. Check the current version of firmware of your camera and lens
- 1-2. Download the file for update
- 1-3. Copy the extracted firmware update program into an SD memory card.
(For a camera using a microSD memory card, please use a microSD memory card.)

Step 2. Procedure for camera body and lens update

Preparation products

1. Fully charged battery

※Updating may fail when the battery is not fully charged.

2. SD Memory Card

※Be sure to format the SD Memory Card with the camera that you are using.

Procedure for update

Step 1. Preparation of update program

1-1. Check the current version of firmware of your camera body and lens

The procedures to check the firmware version of your camera body and lens, are explained in this section.

▼ Camera Body and Lens

1-2. Download the file for update and Extraction of the file

Download the firmware you will use from the website.

▼ For zip file

▼ For exe file

1-3. Copy the extracted firmware update program into an SD memory card.

Copy the firmware file ([xxxxxxx.bin] or [xxxxxxx.lin]) to the SD Memory Card.

* Do not copy 2 or more firmware files ([xxxxxxx.bin] or [xxxxxxx.lin]) to the same SD Memory Card.
Firmware update may fail if 2 or more firmware files are saved in the SD Memory Card.

! [ATTENTION]

Check if the camera is turned off.

- ✓ When installing the firmware using the SD Memory Card slot on PC or external SD Memory Card reader/writer
- ✓ When installing the firmware via USB connection

For the update on camera body and lens, please jump to Step 2.

Step 2. Continue Procedure for update

 Print

 Page top

Area

© Panasonic Corporation
[Site Map](#) | [Terms of Use](#) | [Privacy Policy](#) | [Global Home](#)