



How to use Award WinFLASH utility?

1. Execute WinFlash.exe in the Windows(98SE ,ME,2000 or XP).


This utility user interface is as below. You can choose which options you want to update. Ex. If you want to clear CMOS, to put a check with **Clear CMOS** this item




2. Press **File** button, and choose **Open** this item.




4. Please double check the update option you want. The Block you chose will change color from green to blue.




5. Press **File** button, and choose **Update BIOS** this item or press the **Update BIOS now** icon directly.



Then load BIOS file you allocated again. Then press **Open** button when you finish choosing BIOS file.



6. Press Update button to start Update System BIOS.



7. When flash BIOS completed, you will see this message. Press YES to reboot your system.

