


Note: Refer to Faxback Doc. # 1269 for setting this board.



- E5-E6 Connects Clock to video logic
- E8-E9 Connects 8MHz clock to FDC clock divider
- E21-E22 Selects active drive ready signal constantly