

SETTING THE COMMUNICATIONS PORT

The communications port is set via DIP switch 3 (see table below). If there is no other serial device (mouse or serial printer) connected to the computer, set the modem to Com 1. Otherwise, set the modem to be different than the other serial device.

The communications software you are using may require you to indicate in which port you have installed your PC Modem. Make sure your software is set to the same port as the PC Modem.

SWITCH		FUNCTION
3	OFF	Modem is set at com 2.
	ON *	Modem is set at com 1.

* Default Setting

(dkh-07/28/93)