

Telephone Answering System with Voice, LCD, and Timer

The TAD records a dial tone, a siren, beeping, or an operator's voice instead of a caller's message.

The caller hung up without leaving a message or without using the maximum time, and your local phone company does not send out CPC signals.

The TAD does not answer calls.

- * The phone line connection is bad.
- * MASTER POWER is set OFF.
- * You did not install both tapes.

The outgoing announcement does not play.

- * The outgoing message cassette is not correctly installed, or it needs to be replaced.

The outgoing announcement is distorted.

You were too close to the microphone or you spoke too loudly when recording your announcement.

The outgoing announcement or recorded messages are not clear.

- * The tape-handling parts are dirty.
- * The heads need to be demagnetized.
- * The tape is worn out. Turn over the cassette. Replace cassettes at least once a year.

The TAD does not respond to remote control commands.

- * You did not enter the correct remote security code.
 - * The TAD is turned off.
 - * You did not install both tapes.
-